



IntesisBox®

IS-IR-KNX-1i v1.0

User's Manual
Issue Date: 06/2017
r1.0 eng

IntesisBox® 

© Intesis Software S.L.U. 2017 All Rights Reserved.

Information in this document is subject to change without notice. The software described in this document is furnished under a license agreement or nondisclosure agreement. The software may be used only in accordance with the terms of those agreements. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's personal use without the written permission of Intesis Software S.L.U.

Intesis Software S.L.U.
Milà I Fontanals, 1 bis
08700 Igualada
Spain

TRADEMARKS

All trademarks and tradenames used in this document are acknowledged to be the copyright of their respective holders.

Gateway for integration of IR air conditioners into KNX TP-1 (EIB) control systems.

Compatible with AC units, of most AC brands, provided with an IR receiver.

Application's Program Version: 1.0

Order Code: **IS-IR-KNX-1i**

Table of Contents

1	Presentation	6
2	Quick setup.....	7
3	Device Installation	8
3.1	Location selection.....	8
3.2	Connection to IR and location	9
3.3	Connection to KNX.....	11
3.4	Binary Input connection	12
4	Configuration and setup	14
5	ETS Parameters and Configuration	15
5.1	General configuration	16
5.1.1	AC brand	16
5.1.2	Model.....	16
5.1.3	Delay before sending initial “Read” telegrams	16
5.1.4	Scene to execute on bus recovery / startup.....	17
5.1.5	Enable “lock control” objects	17
5.1.6	Enable func “Operation time objects”.....	17
5.1.7	RGB LED mode	18
5.2	AC supported features	18
5.3	Mode.....	19
5.3.1	Enable use of bit-type Mode objects (for control)	19
5.3.2	Enable use of bit-type Mode objects (for status).....	19
5.3.3	Enable use of + / - object for Mode	20
5.3.4	Enable use of Text object for Mode	20
5.4	Fan Speed	21
5.4.1	DPT object type for fan speed	21
5.4.2	Enable use of bit-type Fan Speed objects (for Control)	22
5.4.3	Enable use of bit-type Fan Speed objects (for Status)	22
5.4.4	Enable use of +/- object for Fan Speed	23
5.4.5	Enable use of Text object for Fan Speed.....	23
5.5	Up-Down vanes configuration dialog	24
5.5.1	DPT object type for Vane Up-Down	24
5.5.2	Enable use of bit-type Vane U-D objects (for Control).....	25
5.5.3	Enable use of bit-type Vane U-D objects (for Status)	25
5.5.4	Enable use of +/- obj for Vane Up-Down	26
5.5.5	Enable use of Text object for Vane U-D	26
5.6	Left-Right vanes configuration dialog	27
5.6.1	DPT object type for Vane Left-Right	27
5.6.2	Enable use of bit-type Vane L-R objects (for Control)	28
5.6.3	Enable use of bit-type Vane U-D objects (for Status)	28
5.6.4	Enable use of +/- obj for Vane Left-Right.....	29
5.6.5	Enable use of Text object for Vane U-D	29
5.7	Temperature configuration dialog.....	30
5.7.1	Set Point - Enable use of +/- obj for Setp Temp	30
5.7.2	Set Point - Enable limits on Control_ Setpoint obj	31
5.7.3	Set Point - Periodic sending time	31
5.7.4	Ambient - Transmission of “Status_ AC Ret Temp”	31
5.7.5	Ambient - Periodic sending time	31
5.8	Scene Configuration dialog	32
5.8.1	Enable use of scenes	32
5.8.2	Scenes can be saved from KNX	32
5.8.3	Enable use of bit-field objects for save	33
5.8.4	Enable use of bit-field objects for execute	33
5.8.5	Scene “x” preset.....	34
5.9	Enable use of Open Window	35
5.10	Enable use of Occupancy function	36

5.11 Binary Input “x” configuration dialogs	38
5.11.1 Enable use of Input “x”	38
5.11.2 Contact type	39
5.11.3 Debounce time	39
5.11.4 Disabling function	39
5.11.5 Function	39
6 Electrical and Mechanical features	40
7 List of compatible AC indoor units	41
8 Appendix A – Communication Objects Table	42


1 Presentation



IntesisBox® IS-IR-KNX-1i allows monitoring and control of Air Conditioners from KNX installations.

Compatible with most AC units with an IR receiver.

Great flexibility of integration into your KNX projects. Configuration is made directly from ETS, the database of the device comes with a complete set of communication objects allowing, from a simple and quick integration using the basic objects, allowing a simple and quick integration.



Main features:

- Reduced dimensions and quick installation.
- Includes a USB connector for fast programming download.
- Multiple objects for control and status (bit, byte, characters...) with KNX standard datapoint types.
- Status objects for every control available.
- Special Modes available (Power, Economy, Additional Heating and Additional Cooling).
- Timeout for Open Window and Occupancy. Sleep function also available.
- Control of the AC unit based in the ambient temperature read by the own AC unit, or in the ambient temperature read by any KNX thermostat.
- Total Control and Monitoring of the AC unit from KNX, including monitoring of AC unit's state of internal variables, running hours' counter (for filter maintenance control), and error indication and error code.
- AC unit can be controlled simultaneously by the remote controller of the AC unit and by KNX.
- Up to 5 scenes can be saved and executed from KNX, fixing the desired combination of Operation Mode, Set Temperature, Fan Speed, Vane Position and Remote Controller Lock in any moment by using a simple switching.
- Two binary inputs for potential-free contacts provide the possibility to integrate many types of external devices for window status control (window contacts) and occupancy (presence sensor)

2 Quick setup




Figure 2.1 IS-IR-KNX-1i integration example

1. Check the interface location that best fits the installation (section 3.1)
2. Connect the interface to the KNX bus.
3. Download the ETS database for this product, import it and add it to the current ETS project.
4. Access the parameter section of the IntesisBox device. Notice that parameters for this interface are configured through a specific plugin (section 5).
5. Select the communication objects to be used and other parameters. This step can be omitted if working with the default objects and parameters.
6. Save the configuration file and download the application program.
7. Close the plugin and apply changes when asked.
8. Link the group address from the communication object of the KNX device with the communication object inside the IntesisBox interface.
9. Download the ETS parameters as with any other standard KNX device.

3 Device Installation

3.1 Location selection

Determining that the IntesisBox device will be working as expected in the installation location is an important stage. In order to determine the best location for your IntesisBox device, use the Wireless Controller (the one of your AC unit).

When selecting the installation location, please keep in mind that the IntesisBox device has 2 IR emitters and 1 IR receiver. The 2 emitters increase the installation possibilities allowing many different suitable positions for the device location. On the other hand, the receiver offers the possibility to get the feedback from the IR wireless remote controller so the KNX status objects can be updated with that feedback.




Figure 3.1 IR emitters and IR receiver location

3.2 Connection to IR and location

There is no special requirement to match the IR receiver and the IntesisBox IS-IR-KNX-1i interface. Simply select your model from the list present in the plugin. If your AC unit is not present, please check the compatibility list as in section 7. You can find more information about the IR configuration in section 5.




IMPORTANT: Keep in mind that some furniture and materials (carpets, curtains, glass, metal...) may affect on the IR communication.




NOTE: The IntesisBox device has 2 IR emitters pointing at 2 different locations. Considering this and IR reflections, valid locations for the IntesisBox device may be many and very different depending on each installation. Check section 3.1 for more information.

IntesisBox IS-IR-KNX-1i can be installed in many different locations.


A) Side-by-side with the AC unit



B) In front of the AC unit



C) Under the AC unit



D) Desktop position




Figure 3.2 IR emitters and IR receiver location

Case A: Installed side-by-side with the AC unit. In that case, the signal will travel from the IntesisBox device to the AC unit taking advantage of the rebounds on the floor or other furniture present in the room.

Case B: Installed in front of the AC unit. In that case, the signal will travel from the IntesisBox device directly to the AC unit.

Case C: Installed below the AC unit. In that case, the signal will travel from the IntesisBox device to the AC unit taking advantage of the rebounds on the wall in front of it or other furniture present in the room.

Case D: If you want to place the device on your desktop or any other horizontal surface, please consider the sketch below. In this case, the signal will travel directly from the IntesisBox device to the AC unit.




Figure 3.3 Desktop mounted position

In order not to produce marks or scratches on the surface and also to improve the device stability, you can use the rubber dumpers included in the package. Please, check **Figure 3.4**.




Figure 3.4 Rubber dumpers location

3.3 Connection to KNX

IntesisBox device needs to be connected directly through a KNX TP-1 bus.

To get access to the KNX connector, remove the screw as seen in Figure 3.5.



Figure 3.5 Top lid release and KNX connection

Disconnect power of the KNX bus. Connect the IS-IR-KNX-1i to the KNX TP-1 (EIB) bus using the KNX standard connector (red/grey) of the IS-IR-KNX-1i, respect polarity.

Reconnect power of the KNX bus, and mains power of the AC unit.

3.4 Binary Input connection

IntesisBox IS-IR-KNX.1i interface is equipped with a Binary Input from factory. To use the built-in binary input in all the IR WIFI Controllers, a standard 3,5mm stereo jack connector is required.

Connections will be as in the image below.




Figure 3.6 Binary Input connection

IMPORTANT NOTE: Please, note that you can only connect a presence sensor or a window contact simultaneously. Both sensors cannot work together at same time.

Before proceeding, please check the technical specification of the binary input below:

Potential free binary input

Signal cable length: 5m unshielded, may be extended up to 20m with twisted

Compliant with the following standards:

IEC61000-4-2: level 4 – 15kV (air discharge) - 8kV (contact discharge)

MIL STD 883E-Method 3015-7: class 3B

Once you are sure your installation is compliant with the specifications, please check the presence sensor or window contact you would like to use. Basically, sensors only need to be equipped with a potential free external contact. No matter if the contact is NO (Normally Open) or NC (Normally closed) as you will be able to configure the contact type (NO or NC) of your sensor in the settings of the Binary Input function (Go to Settings menu in the IntesisBox WEB Site).

IMPORTANT NOTE: Please, note that IS-IR-KNX-1i interface will only react if the contact of your sensor is opened or closed. In the case of the presence sensor, the installer needs to decide the specific settings of the presence sensor to be applied. IntesisBox will be not responsible of the incorrect settings or incorrect installations.

Recommendation: In some presence sensors or window contacts it is possible to setup a delay time to the external contact. As you will see in this manual, IntesisBox Settings allow the user to setup a timer before starting with the configured actions. Anyway, we recommend to setup a certain delay time in your presence sensor or window contact to prevent continuous contact changes in a very short period of time.

4 Configuration and setup


This is a fully compatible KNX device which must be configured and setup using standard KNX tool ETS.

Before starting with the configuration, please make sure that the binary inputs (if used) and the USB cable are properly connected to the interface. Make sure as well, that the interface is connected to the KNX bus to allow the proper download of the KNX programming.

In order to proceed with the configuration and set up, it is recommended to follow instructions next:

1. Download and install the latest version of the ETS data base (section 5).
2. Open the product's plugin and make sure that the catalog is in its last available version (section 5).
3. Select your AC brand and model (section 5.1).
4. Download the infrared configuration to the IntesisBox pushing on the "**Download IR parameters**".

NOTE: Check the current connection to the IntesisBox. Notice that in order to send the Infrared configuration, you can use the standard KNX connection (the same used to program the device) or a USB connection.



USB connection is faster than KNX connection. Notice that this is only available for the infrared configuration settings.

5. Proceed with the rest of AC unit settings and other parameters.
6. Proceed with the KNX programming.
7. Download the programming to the interface as any other KNX device.

5 ETS Parameters and Configuration

The IntesisBox IS-IR-KNX-1i interface is configured through ETS. General KNX parameters, such as the physical address, group addresses or DPTs can be configured as usual using the ETS interface. For the specific AC unit configuration and IR communication, the use of the specific plugin included in the ETS database is required.

ETS database for this device can be downloaded from:

https://www.intesisbox.com/intesis/product/media/IS-IR-KNX-1i_ETS_database.zip

Please consult the README.txt file, located inside the downloaded zip file, to find instructions on how to install the database.

Once the database is imported, the plugin can be accessed when editing parameters. To get access to parameters edition, click on the **Parameter** tab, located in the project screen, and then press the specific parameter dialog.




Figure 5.1 ETS Project managing and plugin screen

Remember that before start using the IntesisBox interface along with the AC unit, you need to set up at least the brand and type of your AC unit. Check section 5.1 for more information about it.

IMPORTANT: Please, update the Catalogue before proceeding with the device configuration and programming. The laptop where ETS is running shall have Internet connection to update the catalogue.

5.1 General configuration

Inside this parameter's dialog it is possible to activate or change the parameters shown below:




Figure 5.2 General parameters

5.1.1 AC brand

Use the dropdown menu to select the AC brand of the AC unit you want to control.

In case your AC unit brand is not present, please select the IS-IR-KNX-1i and contact our support department for more information about the Model to select.

5.1.2 Model

Use the dropdown menu to select the AC brand of the AC unit you want to control.

In case your AC unit brand is not present in the AC brand list, please select the IS-IR-KNX-1i and contact our support department for more information about the Model to select.

5.1.3 Delay before sending initial “Read” telegrams

This parameter sets the delay before the interface will send READ telegrams for the group addresses associated on its *Control_* objects on bus recovery or application reset/start-up. All *Control_* objects with both Transmit (**T**) and Update (**U**) flags enabled will send READs and their values will be updated with the response when received.

Valid values go from 10 to 60 seconds. This is to give time enough to other KNX devices on the bus to start-up before sending the READs.

5.1.4 Scene to execute on bus recovery / startup

This parameter executes a selected scene on bus recovery or startup, only if the selected scene has an enabled preset or values previously saved from KNX bus (see Scene Configuration dialog). You can select any of the 5 available scenes.

5.1.5 Enable “lock control” objects

This parameter shows/hide the *Control_Lock Control Obj* communication object which, depending on the sent value, locks or unlocks ALL the *Control_* communication objects except itself.

When a “1” value is sent to this communication object, the remote controller is locked. To be unlocked a “0” value must be sent. The gateway remembers the last value received even if a KNX bus reset/failure happens.

 55: Control_Lock Remote Control [DPT_1.002] - 0-Unlock;1-L...

Figure 5.3 Communication object detail

⚠ Important: If an initial scene is enabled and it has as Value for Remote Lock (unchanged) or unlocked, this would unlock the remote controller because the initial scene has priority over the *Control_Lock Remote Control* communication object.

5.1.6 Enable func “Operation time objects”

This parameter shows/hides the *Status_Operating Hour Counter* and *Status_Operating Second Counter* communication object which counts the number of operating hours for the IS-IR-KNX-1i.

 130: Status_Operating Hour Counter [DPT_7.007] - Number...
 131: Status_Operating Second Counter [DPT_13.100] - Numb...

Figure 5.4 Communication object detail

- If set to “no” the object will not be shown.
- If set to “yes” the *Status_Operation Hour Counter* object will appear.
 - This object can be read and sends its status every time an hour is counted. The gateway keeps that count in memory and the status is sent also after a KNX bus reset/failure. Although this object is marked as a *Status_* object it also can be written to update the counter when needed. To reset the counter should be written a “0” value.

⚠ Important: This object comes by default without the write (**W**) flag activated. If is necessary to write on it, this flag must be activated.

⚠ Important: This object will also return its status, every time a value is written, only if it's different from the existing one.

⚠ Important: If the stored value is 0 hours, the gateway will not send the status to KNX.

5.1.7 RGB LED mode

This parameter determines the working mode of the interface LED.

- If set to “**Always off**” the LED will always be off.
- If set to “**Always on**” the LED will always be on.
- If set to “**Only on changes**” the LED will always change when there is a change of value in any of the active communication objects.

5.2 AC supported features

Select the AC features of your AC unit to match both: the AC unit features with the enabled communication objects and parameters.

Please, select these parameters carefully, otherwise not expected behavior may occur.




Figure 5.5 AC supported features

5.3 Mode

All the parameters in this section are related with the different mode properties and communication objects.

The byte-type communication object for Mode works with the DTP_20.105. Auto mode will be enabled with a “0” value, Heat mode with a “1” value, Cool mode with a “3” value, Fan mode with a “9” value and Dry mode with a “14” value.




Figure 5.6 AC mode additional communication objects

5.3.1 Enable use of bit-type Mode objects (for control)

This parameter shows/hides the bit-type *Control_Mode* objects.

- 4: Control_Mode Auto [DPT_1.002] - 1-Set AUTO mode
- 5: Control_Mode Heat [DPT_1.002] - 1-Set HEAT mode
- 6: Control_Mode Cool [DPT_1.002] - 1-Set COOL mode
- 7: Control_Mode Fan [DPT_1.002] - 1-Set FAN mode
- 8: Control_Mode Dry [DPT_1.002] - 1-Set DRY mode

Figure 5.7 Communication object detail

- If set to “no” the objects will not be shown.
- If set to “yes” the *Control_Mode* objects for Auto, Heat, Cool, Fan and Dry will appear. To activate a mode by using these objects a “1” value has to be sent.

5.3.2 Enable use of bit-type Mode objects (for status)

This parameter shows/hides the bit-type *Status_Mode* objects.

- 74: Status_Mode Auto [DPT_1.002] - 1-AUTO mode is active
- 75: Status_Mode Heat [DPT_1.002] - 1-HEAT mode is active
- 76: Status_Mode Cool [DPT_1.002] - 1-COOL mode is active
- 77: Status_Mode Fan [DPT_1.002] - 1-FAN mode is active
- 78: Status_Mode Dry [DPT_1.002] - 1-DRY mode is active

Figure 5.8 Communication object detail

- If set to “**no**” the objects will not be shown.
- If set to “**yes**” the *Status_Mode* objects for Auto, Heat, Cool, Fan and Dry will appear. When enabled, a mode will return a “1” through its bit-type object.

5.3.3 Enable use of + / - object for Mode

This parameter shows/hides the *Control_Mode* +/- communication object which lets change the indoor unit mode by using two different datapoint types.


 9: Control_Mode -/+ [DPT_1.007] - 0-Decrease;1-Increase

- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Control_Mode* +/- object and a new parameter will appear.

➤ DPT type for +/- Mode Object

This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_Mode* +/- object.

The sequence followed when using this object is shown below:



5.3.4 Enable use of Text object for Mode

This parameter shows/hides the *Status_Mode Text* communication object.

 79: Status_Mode Text [DPT_16.001] - ASCII String

- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Status_Mode Text* object will appear.

5.4 Fan Speed

All the parameters in this section are related with the Fan Speed properties and communication objects.




Figure 5.9 Fan Speed parameters

5.4.1 DPT object type for fan speed

With this parameter is possible to change de DPT for the *Control_Fan Speed* and *Status_Fan Speed* byte-type communication objects. Datapoints Scaling (DPT_5.001) and Enumerated (DPT_5.010) can be selected.

- When “**Enumerated [DPT 5.010]**” is selected, *Control_Fan Speed* and *Status_Fan Speed* communication objects for this DPT will appear. Also, depending on the number of fan speeds selected, these objects will be different.

- 10: Control_Fan Speed [DPT_5.010] - Speed values: 1,2,3,...
- 80: Status_Fan Speed [DPT_5.010] - Speed values: 1,2,3,...

The first fan speed will be selected if a “1” is sent to the *Control*_object. The second fan speed will be selected sending a “2” and so on.

The *Status*_object will always return the value for the fan speed selected.

⚠ Important: In both cases if a “0” value is sent to the *Control*_object, the minimum fan speed will be selected. If a value bigger than “2” (in case of 2 speeds) or bigger than “3” (in case of 3 fan speeds) is sent to the *Control*_object, then the maximum fan speed will be selected.

- When “**Scaling [DPT 5.001]**” is selected, *Control_Fan Speed* and *Status_Fan Speed* communication objects for this DPT will appear. Also, depending on the number of fan speeds selected, these objects will be different.

- 10: Control_Fan Speed [DPT_5.001] - Thresholds: 100*(n+0'5)...
- 80: Status_Fan Speed [DPT_5.001] - 100*n/N %

The formula used to calculate the value to be set in the Control object is '**100*(n+0,5)/N %**', where n is the current fan speed and N the maximum number of fan speeds.

On the other hand, the formula to calculate the status to be read according to the current value is '**100*n/N**', where n is the current fan speed and N the maximum number of fan speeds.


Check this example with 3 fan speeds:

When a value between **0%** and **49%** is sent to the *Control_* object the first fan speed will be selected.

When a value between **50%** and **83%** is sent to the *Control_* object, the second speed will be selected.

When a value between **84%** and **100%** is sent to the *Control_* object, the third speed will be selected.

The *Status_* object will return a **33%** when the first speed is selected, a **67%** for the second one and a **100%** for the third one.



5.4.2 Enable use of bit-type Fan Speed objects (for Control)

This parameter shows/hides the bit-type *Control_Fan Speed* objects.

- 12: Control_Fan Speed 1 [DPT_1.002] - 1-Set Fan Speed 1
- 13: Control_Fan Speed 2 [DPT_1.002] - 1-Set Fan Speed 2
- 14: Control_Fan Speed 3 [DPT_1.002] - 1-Set Fan Speed 3
- 15: Control_Fan Speed 4 [DPT_1.002] - 1-Set Fan Speed 4
- 16: Control_Fan Speed 5 [DPT_1.002] - 1-Set Fan Speed 5
- 17: Control_Fan Speed 6 [DPT_1.002] - 1-Set Fan Speed 6
- 18: Control_Fan Speed 7 [DPT_1.002] - 1-Set Fan Speed 7

- If set to “**no**” the objects will not be shown.
- If set to “**yes**” the *Control_Fan Speed* objects for Speed 1, Speed 2 and Speed 3 (if available) will appear. To activate a Fan Speed by using these objects a “**1**” value has to be sent.

5.4.3 Enable use of bit-type Fan Speed objects (for Status)

This parameter shows/hides the bit-type *Status_Fan Speed* objects.

- 82: Status_Fan Speed 1 [DPT_1.002] - 1-Fan in Speed 1
- 83: Status_Fan Speed 2 [DPT_1.002] - 1-Fan in Speed 2
- 84: Status_Fan Speed 3 [DPT_1.002] - 1-Fan in Speed 3
- 85: Status_Fan Speed 4 [DPT_1.002] - 1-Fan in Speed 4
- 86: Status_Fan Speed 5 [DPT_1.002] - 1-Fan in Speed 5
- 87: Status_Fan Speed 6 [DPT_1.002] - 1-Fan in Speed 6
- 88: Status_Fan Speed 7 [DPT_1.002] - 1-Fan in Speed 7

- If set to “**no**” the objects will not be shown.
- If set to “**yes**” the *Status_Fan Speed* objects for Speed 1, Speed 2 and Speed 3 (if available) will appear. When a Fan Speed is enabled, a “1” value is returned through its bit-type object.

5.4.4 Enable use of +/- object for Fan Speed

This parameter shows/hides the *Control_Fan Speed +/-* communication object which lets you increase/decrease the indoor unit fan speed by using two different datapoint types.

- 19: Control_Fan Speed -/+ [DPT_1.007] - 0-Decrease;1-Incre...


- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Control_Fan Speed +/-* object.

➤ DPT type for +/- Fan Speed Object

This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_Fan Speed +/-* object.

➤ Roll-over Speed at upper/lower limit

This parameter lets choose if roll-over will be enabled (“**yes**”) or disabled (“**no**”) for the *Control_Fan Speed +/-* object.



5.4.5 Enable use of Text object for Fan Speed

This parameter shows/hides the *Status_Fan Speed Text* communication object.

- 89: Status_Fan Speed Text [DPT_16.001] - ASCII String

- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Status_Fan Speed Text* object will appear.

5.5 Up-Down vanes configuration dialog

All the parameters in this section are related with the Vane Up-Down properties and communication objects.

5.5.1 DPT object type for Vane Up-Down

With this parameter is possible to change de DPT for the *Control_Vane Up-Down* and *Status_Vane Up-Down* byte-type communication objects. Datapoints Scaling (DPT_5.001) and Enumerated (DPT_5.010) can be selected.

- When “**Enumerated [DPT 5.010]**” is selected, *Control_Vane Up-Down* and *Status_Vane Up-Down* communication objects for this DPT will appear.

 20: Control_Vanes U-D [DPT_5.010] - Position values: 1,2,3,...

 90: Status_Vanes U-D [DPT_5.010] - Position values: 1,2,3,...

To choose a vane position, values from “1” to “N” can be sent to the *Control*_ object. Each value will correspond to the position (i.e. Value “3” = Position 3).

The *Status*_ object will always return the value for the vane position selected.

 **Important:** If a “0” value is sent to the *Control*_ object, the Position 1 will be selected. If a value bigger than “N” is sent to the *Control*_ object, then the Position N will be selected.

- When “**Scaling [DPT 5.001]**” is selected, *Control_Vane Up-Down* and *Status_Vane Up-Down* communication objects for this DPT will appear.

 20: Control_Vanes U-D [DPT_5.001] - Thresholds: 100*(n+0'5...

 90: Status_Vanes U-D [DPT_5.001] - 100*n/N %

The formula used to calculate the value to be set in the *Control* object is ‘**100*(n+0,5)/N %**’, where n is the current fan speed and N the maximum number of fan speeds.

On the other hand, the formula to calculate the status to be read according to the current value is ‘**100*n/N**’, where n is the current fan speed and N the maximum number of fan speeds.

Check the example with 5 positions:

When a value between **0%** and **29%** is sent to the *Control*_ object the first vane position will be selected.


When a value between **30%** and **49%** is sent to the *Control*_ object, the second vane position will be selected.

When a value between **50%** and **69%** is sent to the *Control*_ object, the third vane position will be selected.

When a value between **70%** and **89%** is sent to the *Control*_ object, the fourth vane position will be selected.

When a value between **90%** and **100%** is sent to the *Control_* object, the fifth vane position will be selected.

The *Status_* object will return a **20%** for the first vane position, a **40%** for the second one, a **60%** for the third one, an **80%** for the fourth one and a **100%** for the fifth and last one.



5.5.2 Enable use of bit-type Vane U-D objects (for Control)

This parameter shows/hides the bit-type *Control_ Vane Up-Down* objects.

- 22: Control_Vanes U-D Pos 1 [DPT_1.002] - 1-Set Position 1
- 23: Control_Vanes U-D Pos 2 [DPT_1.002] - 1-Set Position 2
- 24: Control_Vanes U-D Pos 3 [DPT_1.002] - 1-Set Position 3
- 25: Control_Vanes U-D Pos 4 [DPT_1.002] - 1-Set Position 4
- 26: Control_Vanes U-D Pos 5 [DPT_1.002] - 1-Set Position 5
- 27: Control_Vanes U-D Pos 6 [DPT_1.002] - 1-Set Position 6
- 28: Control_Vanes U-D Pos 7 [DPT_1.002] - 1-Set Position 7
- 29: Control_Vanes U-D Pos 8 [DPT_1.002] - 1-Set Position 8

- If set to “**no**” the objects will not be shown.
- If set to “**yes**” the *Control_ Vane Up-Down* objects for each Position (1 to 5) will appear. To activate a Vane Position by using these objects, a “**1**” value has to be sent.

5.5.3 Enable use of bit-type Vane U-D objects (for Status)

This parameter shows/hides the bit-type *Status_ Vane Up-Down* objects.

- 92: Status_Vanes U-D Pos 1 [DPT_1.002] - 1-Vanes in Position...
- 93: Status_Vanes U-D Pos 2 [DPT_1.002] - 1-Vanes in Position...
- 94: Status_Vanes U-D Pos 3 [DPT_1.002] - 1-Vanes in Position...
- 95: Status_Vanes U-D Pos 4 [DPT_1.002] - 1-Vanes in Position...
- 96: Status_Vanes U-D Pos 5 [DPT_1.002] - 1-Vanes in Position...
- 97: Status_Vanes U-D Pos 6 [DPT_1.002] - 1-Vanes in Position...
- 98: Status_Vanes U-D Pos 7 [DPT_1.002] - 1-Vanes in Position...
- 99: Status_Vanes U-D Pos 8 [DPT_1.002] - 1-Vanes in Position...

- If set to “**no**” the objects will not be shown.
- If set to “**yes**” the *Status_ Vane Up-Down* objects for each Position (1 to N) will appear. When a Vane Position is enabled, a “**1**” value is returned through its bit-type object.

5.5.4 Enable use of +/- obj for Vane Up-Down

This parameter shows/hides the *Control_Vane Up-Down +/-* communication object which lets you change the indoor unit vane position by using two different datapoint types.

 33: Control_Vanes U-D -/+ [DPT_1.007] - 0-Decrease;1-Incre...


- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Control_Vane Up-Down +/-* object.

➤ DPT type for +/- Vane Up-Down obj

This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_Vane Up-Down +/-* object.

➤ Rollover Vane at upper/lower limit

This parameter lets choose if roll-over will be enabled (“**yes**”) or disabled (“**no**”) for the *Vane Up-Down +/-* object.



5.5.5 Enable use of Text object for Vane U-D

This parameter shows/hides the *Status_Vane Up-Down Text* communication object.

 103: Status_Vanes U-D Text [DPT_16.001] - ASCII String

- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Status_Vane Up-Down Text* object will appear.

5.6 Left-Right vanes configuration dialog

All the parameters in this section are related with the Vane Up-Down properties and communication objects.

5.6.1 DPT object type for Vane Left-Right

With this parameter is possible to change de DPT for the *Control_Vane Left-Right* and *Status_Vane Left-Right* byte-type communication objects. Datapoints Scaling (DPT_5.001) and Enumerated (DPT_5.010) can be selected.

- When “**Enumerated [DPT 5.010]**” is selected, *Control_Vane Left-Right* and *Status_Vane Left-Right* communication objects for this DPT will appear.

- 35: Control_Vanes L-R [DPT_5.010] - Position values: 1,2,3,...
- 104: Status_Vanes L-R [DPT_5.010] - Position values: 1,2,3,...

To choose a vane position, values from “1” to “N” can be sent to the *Control_* object. Each value will correspond to the position (i.e. Value “3” = Position 3).

The *Status_* object will always return the value for the vane position selected.

 **Important:** If a “0” value is sent to the *Control_* object, the Position 1 will be selected. If a value bigger than “N” is sent to the *Control_* object, then the Position N will be selected.

- When “**Scaling [DPT 5.001]**” is selected, *Control_Vane Up-Down* and *Status_Vane Up-Down* communication objects for this DPT will appear.

- 35: Control_Vanes L-R [DPT_5.001] - Thresholds: 100*(n+0'5)...
- 104: Status_Vanes L-R [DPT_5.001] - 100*n/N %

The formula used to calculate the value to be set in the Control object is ‘**100*(n+0,5)/N %**’, where n is the current fan speed and N the maximum number of fan speeds.

On the other hand, the formula to calculate the status to be read according to the current value is ‘**100*n/N**’, where n is the current fan speed and N the maximum number of fan speeds.

Check the example with 5 positions:

When a value between **0%** and **29%** is sent to the *Control_* object the first vane position will be selected.


When a value between **30%** and **49%** is sent to the *Control_* object, the second vane position will be selected.

When a value between **50%** and **69%** is sent to the *Control_* object, the third vane position will be selected.

When a value between **70%** and **89%** is sent to the *Control_* object, the fourth vane position will be selected.

When a value between **90%** and **100%** is sent to the *Control_* object, the fifth vane position will be selected.

The *Status_* object will return a **20%** for the first vane position, a **40%** for the second one, a **60%** for the third one, an **80%** for the fourth one and a **100%** for the fifth and last one.



5.6.2 Enable use of bit-type Vane L-R objects (for Control)

This parameter shows/hides the bit-type *Control_ Vane Left-Right* objects.

- 37: Control_Vanes L-R Pos 1 [DPT_1.002] - 1-Set Position 1
- 38: Control_Vanes L-R Pos 2 [DPT_1.002] - 1-Set Position 2
- 39: Control_Vanes L-R Pos 3 [DPT_1.002] - 1-Set Position 3
- 40: Control_Vanes L-R Pos 4 [DPT_1.002] - 1-Set Position 4
- 41: Control_Vanes L-R Pos 5 [DPT_1.002] - 1-Set Position 5
- 42: Control_Vanes L-R Pos 6 [DPT_1.002] - 1-Set Position 6
- 43: Control_Vanes L-R Pos 7 [DPT_1.002] - 1-Set Position 7
- 44: Control_Vanes L-R Pos 8 [DPT_1.002] - 1-Set Position 8

- If set to “**no**” the objects will not be shown.
- If set to “**yes**” the *Control_ Vane Up-Down* objects for each Position (1 to N) will appear. To activate a Vane Position by using these objects, a “**1**” value has to be sent.

5.6.3 Enable use of bit-type Vane U-D objects (for Status)

This parameter shows/hides the bit-type *Status_ Vane Up-Down* objects.

- 106: Status_Vanes L-R Pos 1 [DPT_1.002] - 1-Vanes in Position 1
- 107: Status_Vanes L-R Pos 2 [DPT_1.002] - 1-Vanes in Position 2
- 108: Status_Vanes L-R Pos 3 [DPT_1.002] - 1-Vanes in Position 3
- 109: Status_Vanes L-R Pos 4 [DPT_1.002] - 1-Vanes in Position 4
- 110: Status_Vanes L-R Pos 5 [DPT_1.002] - 1-Vanes in Position 5
- 111: Status_Vanes L-R Pos 6 [DPT_1.002] - 1-Vanes in Position 6
- 112: Status_Vanes L-R Pos 7 [DPT_1.002] - 1-Vanes in Position 7
- 113: Status_Vanes L-R Pos 8 [DPT_1.002] - 1-Vanes in Position 8

- If set to “**no**” the objects will not be shown.
- If set to “**yes**” the *Status_ Vane Up-Down* objects for each Position (1 to N) will appear. When a Vane Position is enabled, a “**1**” value is returned through its bit-type object.

5.6.4 Enable use of +/- obj for Vane Left-Right

This parameter shows/hides the *Control_Vane Left-Right +/-* communication object which lets you change the indoor unit vane position by using two different datapoint types.

 48: Control_Vanes L-R -/+ [DPT_1.007] - 0-Decrease;1-Increase

- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Control_Vane Left-Right +/-* object.

➤ DPT type for +/- Vane Left-Right obj

This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_Vane Left-Right +/-* object.

➤ Rollover Vane at upper/lower limit

This parameter lets choose if roll-over will be enabled (“**yes**”) or disabled (“**no**”) for the *Vane Up-Down +/-* object.



5.6.5 Enable use of Text object for Vane U-D

This parameter shows/hides the *Status_Vane Up-Down Text* communication object.

 117: Status_Vanes L-R Text [DPT_16.001] - ASCII String

- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Status_Vane Up-Down Text* object will appear.

5.7 Temperature configuration dialog

All the parameters in this section are related with the Temperature properties and communication objects.




Figure 5.10 Temperature settings

5.7.1 Set Point - Enable use of +/- obj for Setp Temp

This parameter shows/hides the *Control_Setpoint Temp +/-* communication object which lets you change the indoor unit setpoint temperature by using two different datapoint types.

51: Control_Setpoint Temp -/+ [DPT_1.007] - 0-Decrease;1-Increase

- If set to “**no**” the object will not be shown.
- If set to “**yes**” the *Control_Setpoint Temp +/-* object.

➤ DPT type for +/- Setp Temp object

This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_Setpoint Temp +/-* object.

(Lower limit) **16°C** **17°C** ... **31°C** **32°C** (Upper limit)

- Up / Increase
- Down / Decrease

5.7.2 Set Point - Enable limits on Control_Setpoint obj

This parameter enables to define temperature limits for the *Control_Setpoint Temperature* object.

- If set to “**no**” the setpoint temperature limits for the *Control_Setpoint Temperature* object will be the default: 16°C for the lower limit and 32°C for the upper limit.
- If set to “**yes**” it is possible to define temperature limits for the *Control_Setpoint Temperature* object.

➤ Control_Set Temp Lower limit (°C)

This parameter lets to define the lower limit for the setpoint temperature.

➤ Control_Set Temp Upper limit (°C)

This parameter lets to define the upper limit for the setpoint temperature.

⚠ Important: If a setpoint temperature above the upper defined limit (or below the lower defined limit) is sent through the *Control_Setpoint Temperature* object, it will be **ALWAYS** applied the limit defined.

⚠ Important: When limits are enabled, any setpoint temperature sent to the AC (even through scenes, special modes, etc.) will be limited.

5.7.3 Set Point - Periodic sending time

This parameter lets you change the interval of time (in seconds, from 0 to 255) at the end of which the AC setpoint temperature is sent to the KNX bus. For a “**0**” value, the AC setpoint temperature will ONLY be sent on change. The AC setpoint temperature is sent through the communication object *Status_AC Setpoint Temp*.

 118: Status_AC Setpoint Temperature [DPT_9.001] - °C

5.7.4 Ambient - Transmission of “Status_AC Ret Temp”

This parameter lets to you choose if the AC return temperature will be sent “**only cyclically**”, “**only on change**” or “**cyclically and on change**”. The AC return temperature is sent through the communication object *Status_AC Return Temp*.

 120: Status_IntesisBox Reference Temperature [DPT_9.001] -...

5.7.5 Ambient - Periodic sending time

This parameter will only be available for the “**only cyclically**” and “**cyclically and on change**” options, and lets you change the interval of time (in seconds, from 1 to 255) at the end of which the AC return temperature is sent to the KNX bus.

5.8 Scene Configuration dialog

All the parameters in this section are related with the Scene properties and communication objects. A scene contains values of: On/Off, Mode, Fan speed, Vane position and Setpoint Temperature.




Figure 5.11 Scene configuration settings

5.8.1 Enable use of scenes

This parameter shows/hides the scene configuration parameters and communication objects.

58: Control_Save/Execute Scene [DPT_18.001] - 0..4-Exec1-5;...

- If set to “**no**” the scene parameters and communication objects will not be shown.
- If set to “**yes**” the scene parameters and communication objects will be shown. To execute a scene through the byte-type object, a value from “**0**” to “**4**” has to be sent, correponding each one to a different scene (i.e. “0” = Scene 1;... “4” = Scene 5).

5.8.2 Scenes can be saved from KNX

This parameter shows/hides the *Control_Save/Exec Scene* and all the *Control_Save Scene* (if enabled) communication objects.

- 58: Control_Save/Execute Scene [DPT_18.001] - 0..4-Exec1-5;...
- 59: Control_Save Scene 1 [DPT_1.002] - 1-Save Scene 1
- 60: Control_Save Scene 2 [DPT_1.002] - 1-Save Scene 2
- 61: Control_Save Scene 3 [DPT_1.002] - 1-Save Scene 3
- 62: Control_Save Scene 4 [DPT_1.002] - 1-Save Scene 4
- 63: Control_Save Scene 5 [DPT_1.002] - 1-Save Scene 5

- If set to “**no**” the communication objects will not be shown.
- If set to “**yes**” the communication objects and a new parameter will appear. To store a scene through the byte-type object, a value from “**128**” to “**132**” has to be sent to the object, correponding each one to a different scene (i.e. “128” = Scene 1;... “132” = Scene 5).

➤ Enable use of bit objects for storing scenes (from bus)

If set to “**no**” the objects will not be shown.

If set to “**yes**” the *Control_Store Scene* objects for storing scenes will appear. To store a scene by using these objects, a “**1**” value has to be sent to the scene’s object we want to store (i.e. to store scene 4, a “1” has to be sent to the *Control_Store Scene 4* object).

5.8.3 Enable use of bit-field objects for save

This parameter shows/hides the *Control_Execute Scene* bit-type communication objects.

- 58: Control_Save/Execute Scene [DPT_18.001] - 0..4-Exec1-5;...
- 59: Control_Save Scene 1 [DPT_1.002] - 1-Save Scene 1
- 60: Control_Save Scene 2 [DPT_1.002] - 1-Save Scene 2
- 61: Control_Save Scene 3 [DPT_1.002] - 1-Save Scene 3
- 62: Control_Save Scene 4 [DPT_1.002] - 1-Save Scene 4
- 63: Control_Save Scene 5 [DPT_1.002] - 1-Save Scene 5

- If set to “**no**” the communication objects will not be shown.
- If set to “**yes**” the communication objects will appear. To execute a scene by using these objects, a “**1**” value has to be sent to the scene’s object we want to execute (i.e. to execute scene 4, a “1” has to be sent to the *Control_Execute Scene 4* object).

5.8.4 Enable use of bit-field objects for execute

This parameter shows/hides the *Control_Execute Scene* bit-type communication objects.

- 64: Control_Execute Scene 1 [DPT_1.002] - 1-Execute Scene 1
- 65: Control_Execute Scene 2 [DPT_1.002] - 1-Execute Scene 2
- 66: Control_Execute Scene 3 [DPT_1.002] - 1-Execute Scene 3
- 67: Control_Execute Scene 4 [DPT_1.002] - 1-Execute Scene 4
- 68: Control_Execute Scene 5 [DPT_1.002] - 1-Execute Scene 5

- If set to “**no**” the communication objects will not be shown.
- If set to “**yes**” the communication objects will appear. To execute a scene by using these objects, a “**1**” value has to be sent to the scene’s object we want to execute (i.e. to execute scene 4, a “1” has to be sent to the *Control_Execute Scene 4* object).

5.8.5 Scene “x” preset

This parameter lets you define a preset for a scene (the following description is valid for all the scenes).

- If set to “**no**” the preset for the scene “x” will be disabled.
- If set to “**yes**” the preset will be enabled. When a scene is executed the values configured in the preset will be applied.

⚠ Important: If a scene’s preset is enabled, will not be possible to modify (store) the scene from the KNX bus.

➤ Scene “x” / Value for On-Off

This parameter lets you choose the power of the indoor unit when the scene is executed. The following options are available: “**ON**”, “**OFF**” or “**(unchanged)**”.

➤ Scene “x” / Value for Mode

This parameter lets you choose the mode of the indoor unit when the scene is executed. The following options are available: “**AUTO**”, “**HEAT**”, “**COOL**”, “**FAN**”, “**DRY**”, or “**(unchanged)**”.

➤ Scene “x” / Value for Fan Speed

This parameter lets you choose the fan speed of the indoor unit when the scene is executed. The following options are available: “**SPEED 1**”, “**SPEED 2**”... “**SPEED N**”, or “**(unchanged)**”.

➤ Scene “x” / Value for Vane Up-Down

This parameter lets you choose the vane position of the indoor unit when the scene is executed. The following options are available: “**POSITION 1**”, “**POSITION 2**”... “**POSITION N**”, “**SWIRL**”, “**SWING**” or “**(unchanged)**”.

➤ Scene “x” / Value for Vane Left-Right

This parameter lets you choose the vane position of the indoor unit when the scene is executed. The following options are available: “**POSITION 1**”, “**POSITION 2**”... “**POSITION N**”, “**SWIRL**”, “**SWING**” or “**(unchanged)**”.

➤ Scene “x” / Value for Setp Temp (°C)


This parameter lets you choose the setpoint temperature of the indoor unit when the scene is executed. The following options are available: from “**16°C**” to “**32°C**” (both included), or “**(unchanged)**”.

⚠ Important: If any preset value is configured as “(unchanged)”, the execution of this scene will not change current status of this feature in the AC unit.

⚠ Important: When a scene is executed, Status_Current Scene object shows the number of this scene. Any change in previous items does Status_Current Scene show “No Scene”. Only changes on items marked as “(unchanged)” will not disable current scene.

5.9 Enable use of Open Window

This parameter shows/hides the Control_Window Contact Input communication object which lets you Start/Stop a timeout to switch off the indoor unit.



- If set to “no” the object will not be shown.
- If set to “yes” the Control_Window Contact Input object will appear. If a “1” value is sent to this object, and the indoor unit is already turned on, the switch-off timeout will begin. If a “0” value is sent to this object, the switch-off timeout will stop.

➤ Input Object

This parameter lets you choose between the datapoints **0-Open / 1-Closed Window [DPT_1.009]** and **0-Stop / 1-Start Timeout [DPT_1.010]** for the Control_Switch Off Timeout.

➤ Timeout (min)

This parameter lets you select how much time (in minutes) to wait before switching off the indoor unit.

➤ Reload last Value

If set to “no”, once the switch-off timeout is stopped, any value will be reloaded.

If set to “yes”, once the switch-off timeout is stopped, the last On/Off value sent will be reloaded.

- If a “1” value is sent to the Control_Window Contact Input object after the timeout period, the indoor unit will **turn on**.

- If a “0” value is sent to the *Control_Switch Off Timeout* after the timeout period, no action will be performed.

➤ [Lock ON when Open](#)


If set to “no”, On/Off commands while the window is open will be accepted.

- If a “1” value is sent to the *Control_Switch Off Timeout* object the switch-off timeout period will begin again.
- If a “0” value is sent to the *Control_Switch Off Timeout* object, no action will be performed.

If set to “yes”, On/Off commands, while the window is open, will be saved (but not applied). These commands will be used in the next parameter if set to “yes”.

5.10 Enable use of Occupancy function

This parameter shows/hides the *Control_Occupancy Input* communication object which lets you apply different parameters to the indoor unit depending on the presence/no presence in the room.



54: Control_Occupancy Input [DPT_1.018] - 0-Not Occupied;...

- If set to “no” the object will not be shown.
- If set to “yes” the *Control_Occupancy* object and new parameters will appear. If a “1” value is sent to this object (no room occupancy), the timeout will begin. If a “0” value is sent to this object, the timeout will stop.

Figure 4.33 Parameter detail

➤ Timeout to apply action (minutes)

This parameter lets you choose how much time to wait (in minutes) before executing the action specified in the next parameter ("Action after timeout elapsed").

➤ Action

When **Switch Off AC** is selected, once the timeout has elapsed, the indoor unit will be turned off.

When **Apply Preset Delta** is selected, once the timeout has elapsed, a delta temperature will be applied in order to save energy (decreasing the setpoint when in Heat mode, or increasing the setpoint when in Cool mode). Also new parameters will appear.

➤ Temp delta decrease (HEAT) or increase (COOL) (°C)

This parameter lets configure the delta temperature (increase or decrease) that will be applied when the timeout has elapsed.

⚠ Important: When there is occupancy again after the application of a delta, the same delta will be applied inversely. (i.e. In a room with AC in cool mode and 25°C setpoint temperature, a +2°C delta is applied after the occupancy timeout, setting the setpoint at 27°C because there is no occupancy in the room. If the setpoint is raised to 29°C during that period, when the room is occupied again, a -2°C delta will be applied and the final setpoint temperature will then be 27°C).

➤ Second Action

If set to "**no**" nothing will be applied.

If set to "**yes**", a new timeout will be enabled and two new parameters will appear.

➤ Timeout (2nd)

This parameter lets you choose how much time to wait (in minutes) before executing the action specified in the next parameter ("Action after timeout elapsed").

➤ Action (2nd)

When **Switch-Off** is selected, once the timeout has elapsed, the indoor unit will turn off.

When **Apply Preset Delta** is selected, once the timeout configured is extinguished, a delta temperature will be applied (decreasing the setpoint when in Heat mode, or increasing the setpoint when in Cool mode). Also new parameters will appear.

➤ Temp delta decrease (HEAT) or increase (COOL) (°C)

This parameter lets configure the delta temperature that will be applied when the timeout is extinguished.

⚠ Important: When there is occupancy again after the application of a delta, the same delta will be applied inversely as explained above.

➤ [Reload last On/Off value when Occupied](#)

If set to “**no**”, once the switch-off timeout has elapsed, any value will be reloaded.

If set to “**yes**”, once the switch-off timeout has elapsed, the last On/Off value will be reloaded.

- If a “**1**” value is sent to the *Control_Occupancy* object after the timeout period, the indoor unit will **turn on**.
- If a “**0**” value is sent to the *Control_Occupancy* after the timeout period no action will be performed.

➤ [Lock ON when occupied](#)


If set to “**no**”, On/Off commands while the room is occupied will be accepted.

- If a “**1**” value is sent to the *Control_Switch Off Timeout* object the switch-off timeout period will begin again.
- If a “**0**” value is sent to the *Control_Switch Off Timeout* object, no action will be performed.

If set to “**yes**”, On/Off commands, while the window is open, will be saved (but not applied). These commands will be used in the next parameter if set to “**yes**”.

5.11 *Binary Input “x” configuration dialogs*

All the parameters in this section are related with the binary inputs properties and communication objects.



5.11.1 Enable use of Input “x”

This parameter enables the use of the Input “x”.

- If set to “**no**” the objects will not be shown.
- If set to “**yes**” the *Status_Inx* object(s) and new parameters will appear.

5.11.2 Contact type

This parameter lets choose the behavior that will have the binary input depending on if the contact is normally open or normally closed.

- There are two possible options to configure the contact type: “**NO: Normally Open**” and “**NC: Normally Closed**”.

5.11.3 Debounce time

This parameter lets choose a debounce time (in milliseconds) that will be applied to the contact.

5.11.4 Disabling function

This parameter shows/hides the *Control_Disable Input x* communication object which will let disable/enable the input x.

■ 69: Control_Disable Input 1 [DPT_1.002] - 0-False;1-True

■ 70: Control_Disable Input 2 [DPT_1.002] - 0-False;1-True

- If set to “**no**” any object will be shown.
- When “**DPT 1.003: 0-Disable; 1-Enable**” is selected, the input can be disabled using the value “**0**” and enabled using the value “**1**”.
- When “**DPT 1.002: 1-True (Disable); 0-False (Enable)**” is selected, the input can be disabled using the value “**1**” and enabled using the value “**0**”.


5.11.5 Function

This parameter lets choose the function that will have the binary input. There are 3 different functions available: Occupancy (internal), On/Off and Window Contact (internal).

- When “**Occupancy**” is selected, the binary input “x” will have the same behavior as configured in the parameter “Occupany” (section 5.10).
- When “**On/Off**” is selected, the AC unit will turn off when the binary inpyt “x” is active.
- When “**Window Contact (internal)**” is selected, the binary input “x” will have the same behavior as configured in the parameter “Window Contact” (section 5.9).

6 Electrical and Mechanical features

Enclosure	ABS (V-0). 2,1 mm thickness PC (V-2). 1 mm thickness
Dimensions	81 x 78 x 28 mm
Weight	76 g
Color	Ivory white
Power supply	29V DC, 17mA Supplied through KNX bus
Mounting	Wall and desktop
LED indicators	1 x Device status and KNX programming
Push buttons	1 x KNX programming.
Binary inputs	2 x binary inputs for potential-free contacts. Signal cable length: 5m unshielded, may be extended up to 20m with twisted. Compliant with the following standards: IEC61000-4-2: level 4 - 15kV (air discharge) - 8kV (contact discharge) MIL STD 883E-Method 3015-7: class3B
Console port	Mini USB port for console usage
Configuration	Configuration with ETS
Operating Temperature	From 0°C to 40°C
Operating humidity	<93% HR, no condensation
Stock humidity	<93% HR, no condensation



7 List of compatible AC indoor units.

A list of indoor unit model references compatible with IS-IR-KNX-1 and their available features can be found in:

http://intesis.com/pdf/IntesisBox_IS-IR-xxx-1_AC_Compatibility.pdf

8 Appendix A – Communication Objects Table

TOPIC	OBJECT NUMBER	NAME	LENGTH	DATAPoint TYPE		FLAGS				FUNCTION
				DPT_NAME	DPT_ID	R	W	T	U	
On/Off	1	Control_On/Off	1 bit	DPT_Switch	1.001		W	T		0 - Off; 1-On
Mode	2	Control_Mode	1 byte	DPT_HVACContrMode	20.105		W	T		0 - Auto; 1 - Heat; 3 - Cool; 9 - Fan; 14 - Dry
	3	Control_Mode Cool/Heat	1 bit	DPT_Heat/Cool	1.100		W	T		0 - Cool; 1 - Heat
	4	Control_Mode Auto	1 bit	DPT_Bool	1.002		W	T		1 - Auto
	5	Control_Mode Heat	1 bit	DPT_Bool	1.002		W	T		1 - Heat
	6	Control_Mode Cool	1 bit	DPT_Bool	1.002		W	T		1 - Cool
	7	Control_Mode Fan	1 bit	DPT_Bool	1.002		W	T		1 - Fan
	8	Control_Mode Dry	1 bit	DPT_Bool	1.002		W	T		1 - Dry
	9	Control_Mode +/-	1 bit	DPT_Step	1.007		W			0 - Decrease; 1 - Increase
		Control_Mode +/-	1 bit	DPTUpDown	1.008		W			0 - Up; 1 - Down
Fan Speed	10	Control_Fan Speed / N Speeds	1 byte	DPT_Scaling	5.001		W	T		100*(n+0,5)/N %
		Control_Fan Speed / N Speeds	1 byte	DPT_Enumerated	5.010		W	T		1 - Speed1; 2 - Speed2; 3 - Speed3; 4 - Speed4; 5 - Speed5; 6 - Speed6; 7 - Speed7
	11	Control_Fan Speed Man/Auto	1 bit	DPT_Bool	1.002		W	T		0 - Manual; 1 - Auto
	12	Control_Fan Speed 1	1 bit	DPT_Bool	1.002		W	T		1 - Fan Speed 1
	13	Control_Fan Speed 2	1 bit	DPT_Bool	1.002		W	T		1 - Fan Speed 2
	14	Control_Fan Speed 3	1 bit	DPT_Bool	1.002		W	T		1 - Fan Speed 3
	15	Control_Fan Speed 4	1 bit	DPT_Bool	1.002		W	T		1 - Fan Speed 4
	16	Control_Fan Speed 5	1 bit	DPT_Bool	1.002		W	T		1 - Fan Speed 5
	17	Control_Fan Speed 6	1 bit	DPT_Bool	1.002		W	T		1 - Fan Speed 6

Vanes	18	Control_Fan Speed 7	1 bit	DPT_Bool	1.002	W	T	1 - Fan Speed 7
	19	Control_Fan Speed +/-	1 bit	DPT_Step	1.007	W	T	0 - Decrease; 1 - Increase
		Control_Fan Speed +/-	1 bit	DPTUpDown	1.008	W	T	0 - Up; 1 - Down
	20	Control_Vane Up-Down / N pos	1 byte	DPT_Scaling	5.001	W	T	100*(n+0,5)/N %
		Control_Vane Up-Down / N pos	1 byte	DPT_Enumerated	5.010	W	T	1 - Pos1; 2 - Pos2; 3 - Pos3; 4 - Pos4; 5 - Pos5; 6 - Pos6; 7 - Pos7; 8 - Pos8
	21	Control_Vane Up-Down Man/Auto	1 bit	DPT_Bool	1.002	W	T	0 - Manual; 1 - Auto
	22	Control_Vane Up-Down Pos1	1 bit	DPT_Bool	1.002	W	T	1 - Position 1
	23	Control_Vane Up-Down Pos2	1 bit	DPT_Bool	1.002	W	T	1 - Position 2
	24	Control_Vane Up-Down Pos3	1 bit	DPT_Bool	1.002	W	T	1 - Position 3
	25	Control_Vane Up-Down Pos4	1 bit	DPT_Bool	1.002	W	T	1 - Position 4
	26	Control_Vane Up-Down Pos5	1 bit	DPT_Bool	1.002	W	T	1 - Position 5
	27	Control_Vane Up-Down Pos6	1 bit	DPT_Bool	1.002	W	T	1 - Position 6
	28	Control_Vane Up-Down Pos7	1 bit	DPT_Bool	1.002	W	T	1 - Position 7
	29	Control_Vane Up-Down Pos8	1 bit	DPT_Bool	1.002	W	T	1 - Position 8
	30	Control_Vane Up-Down Swing	1 bit	DPT_Bool	1.002	W	T	0 - Stop; 1 - Swing
	31	Control_Vane Up-Down Swirl	1 bit	DPT_Bool	1.002	W	T	0 - Stop; 1 - Swirl
	32	Control_Vane Up-Down Wide	1 bit	DPT_Bool	1.002	W	T	0 - Stop; 1 - Wide
	33	Control_Vane Up-Down +/-	1 bit	DPT_Step	1.007	W		0 - Decrease; 1 - Increase
		Control_Vane Up-Down +/-	1 bit	DPTUpDown	1.008	W		0 - Up; 1 - Down
	34	Control_Vane Up-Down Move Pos	1 bit	DPT_Trigger	1.002	W	T	0,1 Move Position
	35	Control_Vane Left-Right / N pos	1 byte	DPT_Scaling	5.001	W	T	100*(n+0,5)/N %
		Control_Vane Left-Right / N pos	1 byte	DPT_Enumerated	5.010	W	T	1 - Pos1; 2 - Pos2; 3 - Pos3; 4 - Pos4; 5 - Pos5; 6 - Pos6; 7 - Pos7; 8 - Pos8
	36	Control_Vane Left-Right Man/Auto	1 bit	DPT_Bool	1.002	W	T	0 - Manual; 1 - Auto
	37	Control_Vane Left-Right Pos1	1 bit	DPT_Bool	1.002	W	T	1 - Position 1

	38	Control_Vane Left-Right Pos2	1 bit	DPT_Bool	1.002	W	T	1 - Position 2
	39	Control_Vane Left-Right Pos3	1 bit	DPT_Bool	1.002	W	T	1 - Position 3
	40	Control_Vane Left-Right Pos4	1 bit	DPT_Bool	1.002	W	T	1 - Position 4
	41	Control_Vane Left-Right Pos5	1 bit	DPT_Bool	1.002	W	T	1 - Position 5
	42	Control_Vane Left-Right Pos6	1 bit	DPT_Bool	1.002	W	T	1 - Position 6
	43	Control_Vane Left-Right Pos7	1 bit	DPT_Bool	1.002	W	T	1 - Position 7
	44	Control_Vane Left-Right Pos8	1 bit	DPT_Bool	1.002	W	T	1 - Position 8
	45	Control_Vane Left-Right Swing	1 bit	DPT_Bool	1.002	W	T	0 - Stop; 1 - Swing
	46	Control_Vane Left-Right Swirl	1 bit	DPT_Bool	1.002	W	T	0 - Stop; 1 - Swirl
	47	Control_Vane Left-Right Wide	1 bit	DPT_Bool	1.002	W	T	0 - Stop; 1 - Wide
	48	Control_Vane Left-Right +/-	1 bit	DPT_Step	1.007	W		0 - Decrease; 1 - Increase
		Control_Vane Left-Right +/-	1 bit	DPTUpDown	1.008	W		0 - Up; 1 - Down
	49	Control_Vane Left-Right Move Pos	1 bit	DPT_Trigger	1.002	W	T	0,1 Move Position
Temperature	50	Control_Setpoint Temperature	2 byte	DPT_Value_Temp	9.001	W	T	16°C to 32°C
	51	Control_Setpoint Temp +/-	1 bit	DPT_Step	1.007	W		0 - Decrease; 1 - Increase
		Control_Setpoint Temp +/-	1 bit	DPTUpDown	1.008	W		0 - Up; 1 - Down
Window	52	Control_Ambient Temperature	2 byte	DPT_Value_Temp	9.001	W	T	°C value
	53	Control_Window Contact Input	1 bit	DPT_Window_Door	1.019	W	T	0 - Closed; 1 - Open
Occupancy	54	Control_Occupancy Input	1 bit	DPT_Occupancy	1.018	W	T	0 - Not Occupied; 1 - Occupied
Locking	55	Control_Lock Remote Control	1 bit	DPT_Bool	1.002	W	T	0 - Unlocked; 1 - Locked
Operating Time	56	Control_Operating Hour Counter	2 byte	DPT_Time (Hours)	7.007	W	T	Number of operating hours
	57	Control_Operating Second Counter	2 byte	DPT_Time_Lag (Sec)	13.100	W	T	Number of operating seconds
Scenes	58	Control_Save/Exec Scene	1 byte	DPT_SceneControl	18.001	W		0 to 4 - Exec. Scene 1 to 5; 128 to 132 - Save Scene 1 to 5
	59	Control_Store Scene1	1 bit	DPT_Bool	1.002	W		1 - Store Scene
	60	Control_Store Scene2	1 bit	DPT_Bool	1.002	W		1 - Store Scene

	61	Control_Store Scene3	1 bit	DPT_Bool	1.002		W		1 - Store Scene
	62	Control_Store Scene4	1 bit	DPT_Bool	1.002		W		1 - Store Scene
	63	Control_Store Scene5	1 bit	DPT_Bool	1.002		W		1 - Store Scene
	64	Control_Execute Scene1	1 bit	DPT_Bool	1.002		W		1 - Execute Scene
	65	Control_Execute Scene2	1 bit	DPT_Bool	1.002		W		1 - Execute Scene
	66	Control_Execute Scene3	1 bit	DPT_Bool	1.002		W		1 - Execute Scene
	67	Control_Execute Scene4	1 bit	DPT_Bool	1.002		W		1 - Execute Scene
	68	Control_Execute Scene5	1 bit	DPT_Bool	1.002		W		1 - Execute Scene
Disabling	69	Control_Disable Input 1	1 bit	DPT_Bool	1.002		W	T	0 - Enable; 1 - Disable
		Control_Disable Input 1	1 bit	DPT_Enable	1.003		W	T	0 - Disable; 1 - Enable
	70	Control_Disable Input 2	1 bit	DPT_Bool	1.002		W	T	0 - Enable; 1 - Disable
		Control_Disable Input 2	1 bit	DPT_Enable	1.003		W	T	0 - Disable; 1 - Enable

On/Off	71	Status_On/Off	1 bit	DPT_Switch	1.001	R		T	0 - Off; 1-On
Mode	72	Status_Mode	1 byte	DPT_HVACContrMode	20.105	R		T	0 - Auto; 1 - Heat; 3 - Cool; 9 - Fan; 14 - Dry
	73	Status_Mode Cool/Heat	1 bit	DPT_Heat/Cool	1.100	R		T	0 - Cool; 1 - Heat
	74	Status_Mode Auto	1 bit	DPT_Bool	1.002	R		T	1 - Auto
	75	Status_Mode Heat	1 bit	DPT_Bool	1.002	R		T	1 - Heat
	76	Status_Mode Cool	1 bit	DPT_Bool	1.002	R		T	1 - Cool
	77	Status_Mode Fan	1 bit	DPT_Bool	1.002	R		T	1 - Fan
	78	Status_Mode Dry	1 bit	DPT_Bool	1.002	R		T	1 - Dry

	79	Status_Mode Text	14 byte	DPT_String_8859_1	16.001	R	T	ASCII String
Fan Speed	80	Status_Fan Speed / N Speeds	1 byte	DPT_Scaling	5.001	R	T	100*(n+0,5)/N %
		Status_Fan Speed / N Speeds	1 byte	DPT_Enumerated	5.010	R	T	1 - Speed1; 2 - Speed2; 3 - Speed3; 4 - Speed4; 5 - Speed5; 6 - Speed6; 7 - Speed7
	81	Status_Fan Speed Man/Auto	1 bit	DPT_Bool	1.002	R	T	0 - Manual; 1 - Auto
	82	Status_Fan Speed 1	1 bit	DPT_Bool	1.002	R	T	1 - Speed 1
	83	Status_Fan Speed 2	1 bit	DPT_Bool	1.002	R	T	1 - Speed 2
	84	Status_Fan Speed 3	1 bit	DPT_Bool	1.002	R	T	1 - Speed 3
	85	Status_Fan Speed 4	1 bit	DPT_Bool	1.002	R	T	1 - Speed 4
	86	Status_Fan Speed 5	1 bit	DPT_Bool	1.002	R	T	1 - Speed 5
	87	Status_Fan Speed 6	1 bit	DPT_Bool	1.002	R	T	1 - Speed 6
	88	Status_Fan Speed 7	1 bit	DPT_Bool	1.002	R	T	1 - Speed 7
	89	Status_Fan Speed Text	14 byte	DPT_String_8859_1	16.001	R	T	ASCII String
Vanes	90	Status_Vane Up-Down / 8 pos	1 byte	DPT_Scaling	5.001	R	T	100*(n+0,5)/N %
		Status_Vane Up-Down / 8 pos	1 byte	DPT_Enumerated	5.010	R	T	1 - Pos1; 2 - Pos2; 3 - Pos3; 4 - Pos4; 5 - Pos5; 6 - Pos6; 7 - Pos7; 8 - Pos8
	91	Status_Vane Man/Auto	1 bit	DPT_Bool	1.002	R	T	0 - Manual; 1 - Auto
	92	Status_Vane Up-Down Pos1	1 bit	DPT_Bool	1.002	R	T	1 - Position 1
	93	Status_Vane Up-Down Pos2	1 bit	DPT_Bool	1.002	R	T	1 - Position 2
	94	Status_Vane Up-Down Pos3	1 bit	DPT_Bool	1.002	R	T	1 - Position 3
	95	Status_Vane Up-Down Pos4	1 bit	DPT_Bool	1.002	R	T	1 - Position 4
	96	Status_Vane Up-Down Pos5	1 bit	DPT_Bool	1.002	R	T	1 - Position 5
	97	Status_Vane Up-Down Pos6	1 bit	DPT_Bool	1.002	R	T	1 - Position 6
	98	Status_Vane Up-Down Pos7	1 bit	DPT_Bool	1.002	R	T	1 - Position 7
	99	Status_Vane Up-Down Pos8	1 bit	DPT_Bool	1.002	R	T	1 - Position 8
	100	Status_Vane Up-Down Swing	1 bit	DPT_Bool	1.002	R	T	0 - Stop; 1 - Swing

	101	Status_Vane Up-Down Swirl	1 bit	DPT_Bool	1.002	R	T	0 - Stop; 1 - Swirl
	102	Status_Vane Up-Down Wide	1 bit	DPT_Bool	1.002	R	T	0 - Stop; 1 - Wide
	103	Status_Vane Up-Down Text	14 byte	DPT_String_8859_1	16.001	R	T	ASCII String
	104	Status_Vane Left-Right / 8 pos	1 byte	DPT_Scaling	5.001	R	T	100*(n+0,5)/N %
		Status_Vane Left-Right / 8 pos	1 byte	DPT_Enumerated	5.010	R	T	1 - Pos1; 2 - Pos2; 3 - Pos3; 4 - Pos4; 5 - Pos5; 6 - Pos6; 7 - Pos7; 8 - Pos8
	105	Status_Vane Left-Right Man/Auto	1 bit	DPT_Bool	1.002	R	T	0 - Manual; 1 - Auto
	106	Status_Vane Left-Right Pos1	1 bit	DPT_Bool	1.002	R	T	1 - Position 1
	107	Status_Vane Left-Right Pos2	1 bit	DPT_Bool	1.002	R	T	1 - Position 2
	108	Status_Vane Left-Right Pos3	1 bit	DPT_Bool	1.002	R	T	1 - Position 3
	109	Status_Vane Left-Right Pos4	1 bit	DPT_Bool	1.002	R	T	1 - Position 4
	110	Status_Vane Left-Right Pos5	1 bit	DPT_Bool	1.002	R	T	1 - Position 5
	111	Status_Vane Left-Right Pos6	1 bit	DPT_Bool	1.002	R	T	1 - Position 6
	112	Status_Vane Left-Right Pos7	1 bit	DPT_Bool	1.002	R	T	1 - Position 7
	113	Status_Vane Left-Right Pos8	1 bit	DPT_Bool	1.002	R	T	1 - Position 8
	114	Status_Vane Left-Right Swing	1 bit	DPT_Bool	1.002	R	T	0 - Stop; 1 - Swing
	115	Status_Vane Left-Right Swirl	1 bit	DPT_Bool	1.002	R	T	0 - Stop; 1 - Swirl
	116	Status_Vane Left-Right Wide	1 bit	DPT_Bool	1.002	R	T	0 - Stop; 1 - Wide
	117	Status_Vane Left-Right Text	14 byte	DPT_String_8859_1	16.001	R	T	ASCII String
Temperature	118	Status_AC Setpoint Temp	2 byte	DPT_Value_Temp	9.001	R	T	16°C to 32°C
	119	Status_IntesisBox Ambient Temp	2 byte	DPT_Value_Temp	9.001	R	T	°C value
	120	Status_IntesisBox Reference Temp	2 byte	DPT_Value_Temp	9.001	R	T	°C value
Error	121	Status_Error/Alarm	1 bit	DPT_Alarm	1.005	R	T	0 - No Alarm; 1 - Alarm
	122	Status_Error Code	2 byte	Enumerated		R	T	0 - No Error; Any other see user's manual
	123	Status_Error Text code	14 byte	DPT_String_8859_1	16.001	R	T	2 char Error; Empty - none

Window	124	Status_ Window Contact Sensor	1 bit	DPT_Window_Door	1.019	R	T	0 - Closed; 1 - Open
	125	Status_ Window Contact Step	8 bit	Enumerated		R	T	0-Window Closed; 1-Window Open; 2-AC switched off
Occupancy	126	Status_ Occupancy Sensor	1 bit	DPT_Occupancy	1.018	R	T	0 – Not Occupied; 1 – Occupied
	127	Status_ Occupancy Mode	8 bit	DPT_OCC_MODE	20.003	R	T	0 – Occupied; 1 – Stand by; 2 – Not Occupied
	128	Status_ Occupancy State	8 bit	Enumerated		R	T	0 - Occupied; 1 - Unoccupied; 2 - Action1; 3 - Action2
	129	Status_ Lock Remote Control	1 bit	DPT_Bool	1.002	R	T	0 - Unlocked; 1 – Locked
Counter	130	Status_ Operating Hour Counter	2 byte	DPT_Value_2_Ucount	7.001	R	T	Number of operating hours
	131	Status_ Operating Second Counter	2 byte	DPT_Value_2_Ucount	13.100	R	T	Number of operating seconds
Scene	132	Status_ Current Scene	1 byte	DPT_SceneNumber	17.001	R	T	0 to 4 - Scene 1 to 5; 63 - No Scene