



fieldserver

Driver Manual

FS-8700-127 Hanning & Kahl

APPLICABILITY & EFFECTIVITY

Effective for all systems manufactured after June 2023.



Driver Revision: 1.00
Document Revision: 11.B



The Safety Company

MSA Safety
1000 Cranberry Woods Drive
Cranberry Township, PA 16066 USA
Website: www.MSAsafety.com

U.S. Support Information:

+1 408 964-4443
+1 800 727-4377
Email: smc-support@msasafety.com

EMEA Support Information:

+31 33 808 0590
Email: smc-support.emea@msasafety.com

Contents

1	Description.....	4
2	Hardware Connections	5
2.1	Hardware Connection Tips / Hints.....	5
3	Data Array Parameters.....	6
4	Client Side Configuration	7
4.1	Client Side Connection Parameters	7
4.2	Client Side Node Parameters.....	7
4.3	Client Side Map Descriptor Parameters	8
4.3.1	FieldServer Specific Map Descriptor Parameters	8
4.3.2	Driver Related Map Descriptor Parameters	8
4.3.3	Timing Parameters	8
4.4	Map Descriptor Examples	9
4.4.1	Read Data	9
4.4.2	Read Data and Keep History	10
5	Server Side Configuration	11
5.1	Server Side Connection Parameters.....	11
5.2	Server Side Node Parameters.....	11
5.3	Server Side Map Descriptor Parameters	12
5.3.1	FieldServer Specific Map Descriptor Parameters	12
5.3.2	Driver Specific Map Descriptor Parameters	12
5.4	Map Descriptor Example – SMD_HCSR_01 Map Descriptor to Serve HCS-R Clients	12
6	Reference	13
6.1	How Client Stores Data	13
6.1.1	Data_Type is Ana_Input or Not Specified.....	13
6.1.2	Data_Type is Digi_Input.....	14
6.2	How Server Expects Data	15
6.2.1	Data_Type is Ana_Input or Not Specified.....	15
6.2.2	Data_Type is Digi_Input.....	15

1 Description

The Hanning & Kahl HCS-R driver allows the transfer of data from devices over RS-232 HCS-R protocol. Data is read from HCS-R and current data stored in a specified memory area. The driver can store the data with its loop data status distinct memory areas depending on whether the data is on loop or from loop. The driver is based on section 10.5 of Hanning & Kahl – part number 40801121. The FieldServer can act as a Client or Server.


Max Nodes Supported

FieldServer Mode	Nodes	Comments
Client	1	Only 1 virtual client per port allowed on multidrop systems.
Server	1	This is a protocol limit, maximum devices that can be polled by Client.

2 Hardware Connections

The FieldServer is connected to the Hanning & Kahl HCS-R as shown in the connection drawings below.

NOTE: Configure the HCS-R according to manufacturer's instructions.



FS-8917-02 Pinouts

FS Function	RJ45 Pin#	DB9F Pin#	Color
RX	1	3	White
GND	4	5	Green
TX	8	2	Blue

2.1 Hardware Connection Tips / Hints

Loop back RTS CTS if it is required by the other device.

3 Data Array Parameters

Data Arrays are “protocol neutral” data buffers for storage of data to be passed between protocols. It is necessary to declare the data format of each of the Data Arrays to facilitate correct storage of the relevant data.

Section Title	Function	Legal Values
Data_Arrays		
Column Title	Function	Legal Values
Data_Array_Name	Provide name for Data Array.	Up to 15 alphanumeric characters
Data_Array_Format	Provide data format. Each Data Array can only take on one format.	Float, Bit, Byte, UInt16, UInt32, Sint16, Sint32
Data_Array_Length	Number of Data Objects. Must be larger than the data storage area required by the Map Descriptors for the data being placed in this array.	1-10000

Example

```
// Data Arrays
Data_Arrays
Data_Array_Name , Data_Array_Format , Data_Array_Length
DA_CURRENT , UInt16 , 22
DI_FromLoop01 , Bit , 22
DI_OnLoop01 , Bit , 22
DI_FromLoop02 , Bit , 22
DI_OnLoop02 , Bit , 22
DI_FromLoop03 , Bit , 22
DI_OnLoop03 , Bit , 22
DI_FromLoop04 , Bit , 22
DI_OnLoop04 , Bit , 22
```

Configuring the FieldServer

4 Client Side Configuration

For detailed information on FieldServer configuration, refer to the FieldServer Configuration Manual. The information that follows describes how to expand upon the factory defaults provided in the configuration files included with the FieldServer (see “.csv” sample files provided with the FieldServer).

This section documents and describes the parameters necessary for configuring the FieldServer to communicate with the HCS-R Server.

The configuration file tells the FieldServer about its interfaces, and the routing of data required. In order to enable the FieldServer for HCS-R communications, the driver independent FieldServer buffers need to be declared in the “Data Arrays” section, the destination device addresses need to be declared in the “Client Side Nodes” section, and the data required from the servers needs to be mapped in the “Client Side Map Descriptors” section. Details on how to do this can be found below.

NOTE: In the following tables, * indicates an optional parameter and bold legal values are default.

4.1 Client Side Connection Parameters

Section Title	Connections	Column Title	Function	Legal Values
	Connections	Port	Specify which port the device is connected to the FieldServer.	P1-P2, R1-R2 ¹
	Connections	Protocol	Specify protocol used.	HCS-R, HCSR, H&K HCS-R
	Connections	Baud*	Specify baud rate.	9600 (Vendor limitation)
	Connections	Parity*	Specify parity.	None (Vendor limitation)
	Connections	Data_Bits*	Specify data bits.	8 (Vendor limitation)
	Connections	Stop_Bits*	Specify stop bits.	1 (Vendor limitation)
	Connections	Poll_Delay*	Time between internal polls.	0-32000 seconds, 0.05 seconds

Example

```
// Client Side Connections
Connections
Port      , Protocol  , Baud    , Parity   , Poll_Delay
P1        , HCS-R    , 9600   , None    , 0.100s
```

4.2 Client Side Node Parameters

Section Title	Nodes	Column Title	Function	Legal Values
	Nodes	Node_Name	Provide name for node.	Up to 32 alphanumeric characters
	Nodes	Node_ID	HCS-R station address of physical server Node.	240 (Protocol limit)
	Nodes	Protocol	Specify protocol used.	HCS-R, HCSR, H&K HCS-R
	Nodes	Port	Port that connects the device to the FieldServer.	P1-P2, R1-R2

Example

```
// Client Side Nodes
Nodes
Node_Name  , Node_ID   , Protocol  , Port
DEV1      , 1         , InfraTox , R1
```

¹ Not all ports shown are necessarily supported by the hardware. Consult the appropriate Instruction manual for details of the ports available on specific hardware.

Configuring the FieldServer

4.3 Client Side Map Descriptor Parameters

4.3.1 FieldServer Specific Map Descriptor Parameters

Column Title	Function	Legal Values
Map_Descriptor_Name	Name of this Map Descriptor.	Up to 32 alphanumeric characters
Data_Array_Name	Name of Data Array where data is to be stored in the FieldServer.	One of the Data Array names from “Data Array” section above
Data_Array_Offset	Starting location in Data Array.	0 to (Data_Array_Length-1) as specified in “Data_Array” section
Function	Function of Client Map Descriptor.	RDBC, Passive_Client

4.3.2 Driver Related Map Descriptor Parameters

Column Title	Function	Legal Values
Node_Name	Name of Node from which data is fetched.	One of the Node names specified in “Client Node Descriptor” above
HCSR_OnFrom	For Passive_Client Map Descriptor specify whether data From Loop or On Loop or both should be stored.	On, From, OnFrom
HCSR_Loop	For Passive_Client Map Descriptor specify loop number for which data should be stored.	1,2,3,4
Length*	Length of Map Descriptor: 22 (min) for RDBC Map Descriptor 24 if data_type is Dig_Input 21 for Passive_Client Map Descriptor It also depends upon HCSR_Data_Stages parameter. Refer to Section 6 .	22 or 24, 21
Data_Type*	Specify how data will be stored. Refer to Section 6.1 .	Ana_Input Digi_Input
HCSR_Data_Stages*	Specify the number of stages to keep history of data changes. 0 and 1 means no history.	0,1,2,3

4.3.3 Timing Parameters

Column Title	Function	Legal Values
Scan_Interval	Rate at which data is polled	≥0.001s

4.4 Map Descriptor Examples

4.4.1 Read Data

RDBC Map Descriptors are used to poll for data, Passive_Client Map Descriptors are used to store the data for various loops. Refer to [Section 6.1](#) for data storage format.

Map_Descriptors						
Map_Descriptor_Name	, Data_Array_Name	, Data_Array_Offset	, Function	, Node_name	, Length	, Scan_Interval
CMD_DI_HCSR_01	, DA_CURRENT	, 0	, RDBC	, Node_A	, 22	, 5

Example comments:

- Function – Must be RDBC to enable polling.
- Scan_Interval – This setting results in the CMD_DI Map Descriptor polling HCS-R Node_A every 5 seconds.

Map_Descriptors						
Map_Descriptor_Name	, Data_Array_Name	, Data_Array_Offset	, Function	, Node_name		
CMD_FromLoop_01	, DI_FromLoop01	, 0	, Passive_Client	, Node_A		
CMD_OnLoop_01	, DI_OnLoop01	, 0	, Passive_Client	, Node_A		
CMD_FromLoop_02	, DI_FromLoop02	, 0	, Passive_Client	, Node_A		
CMD_OnLoop_02	, DI_OnLoop02	, 0	, Passive_Client	, Node_A		
CMD_FromLoop_03	, DI_FromLoop03	, 0	, Passive_Client	, Node_A		
CMD_OnLoop_03	, DI_OnLoop03	, 0	, Passive_Client	, Node_A		
CMD_FromLoop_04	, DI_FromLoop04	, 0	, Passive_Client	, Node_A		
CMD_OnLoop_04	, DI_OnLoop04	, 0	, Passive_Client	, Node_A		
, Length	, HCSR_Onfrom	, HCSR_Loop				
, 21	, From	, 1				
, 21	, On	, 1				
, 21	, From	, 2				
, 21	, On	, 2				
, 21	, From	, 3				
, 21	, On	, 3				
, 21	, From	, 4				
, 21	, On	, 4				

Example comments:

- Data_Array_Name – Parameter defined in Data Array section.
- Data_Array_Offset – The starting location of data to serve within the Data Array.
- Function – Passive_Client Map Descriptors are used to store data returned by response.
- Length – Maximum number of placeholders for data storage.

Configuring the FieldServer

4.4.2 Read Data and Keep History

This Map Descriptor allows the storage of data history. The driver divides the Data Array into sections corresponding to the number of HCSR_Data_Stages. Current data (stage1) will be stored in the first section and oldest (last stage) data will be stored in the last section in the Data array. Data will be shifted to next Stage only on change.

Map_Descriptors
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Length , Scan_Interval , HCSR_Data_Stages
CMD_DI_HCSR_01 , DA_CURRENT , 0 , RDBC , Node_A , 72 , 5 , 3

Map_Descriptors
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name
CMD_FromLoop_01 , DI_FromLoop01 , 0 , Passive_Client , Node_A
CMD_OnLoop_01 , DI_OnLoop01 , 0 , Passive_Client , Node_A
CMD_FromLoop_02 , DI_FromLoop02 , 0 , Passive_Client , Node_A
CMD_OnLoop_02 , DI_OnLoop02 , 0 , Passive_Client , Node_A
CMD_FromLoop_03 , DI_FromLoop03 , 0 , Passive_Client , Node_A
CMD_OnLoop_03 , DI_OnLoop03 , 0 , Passive_Client , Node_A
CMD_FromLoop_04 , DI_FromLoop04 , 0 , Passive_Client , Node_A
CMD_OnLoop_04 , DI_OnLoop04 , 0 , Passive_Client , Node_A
, Length , HCSR_Onfrom , HCSR_Loop , HCSR_Data_Stages
, 63 , From , 1 , 3
, 63 , On , 1 , 3
, 63 , From , 2 , 3
, 63 , On , 2 , 3
, 63 , From , 3 , 3
, 63 , On , 3 , 3
, 63 , From , 4 , 3
, 63 , On , 4 , 3

Example comments:

- HCSR_Data_Stages – The number of data stages (data changes) to be kept as history.

5 Server Side Configuration

For detailed information on FieldServer configuration, please refer to the FieldServer Configuration Manual. The information that follows describes how to expand upon the factory defaults provided in the configuration files included with the FieldServer (see “.csv” sample files provided with the FieldServer).

This section documents and describes the parameters necessary for configuring the FieldServer to communicate with a Hanning & Kahl HCS-R Client.

The configuration file tells the FieldServer about its interfaces, and the routing of data required. In order to enable the FieldServer for HCS-R communications, the driver independent FieldServer buffers need to be declared in the “Data Arrays” section, the FieldServer virtual Node(s) needs to be declared in the “Server Side Nodes” section, and the data to be provided to the clients needs to be mapped in the “Server Side Map Descriptors” section. Details on how to do this can be found below.

NOTE: In the tables below, * indicates an optional parameter with the bold legal value as default.

5.1 Server Side Connection Parameters

Section Title	Connections	Column Title	Function	Legal Values
	Port	Specify which port the device is connected to the FieldServer.		P1-P2, R1-R2 ²
	Protocol	Specify protocol used.		HCS-R, HCSR, H&K HCS-R
	Baud*	Specify baud rate.		9600 (Vendor Limitation)
	Parity*	Specify parity.		None (Vendor Limitation)
	Data_Bits*	Specify data bits.		8 (Vendor Limitation)
	Stop_Bits*	Specify stop bits.		1 (Vendor Limitation)
	Server_Hold_Timeout*	Specifies the time that the FieldServer will reserve the Server side connection while waiting for the Client side to update data in Data_Array (if necessary).		>1.0s, 2.0s

Example

```
// Server Side Connections
Connections
Port      , Protocol   , Baud    , Parity
P1        , HCS-R     , 9600    , None
```

5.2 Server Side Node Parameters

Section Title	Nodes	Column Title	Function	Legal Values
		Node_Name	Provide name for node.	Up to 32 alphanumeric characters
		Node_ID	Station address of physical server Node.	240
		Protocol	Specify protocol used.	HCS-R, HCSR, H&K HCS-R
		Server_Hold_Timeout*	Specifies the time that the FieldServer will reserve the Server side connection while waiting for the Client side to update data in Data_Array (if necessary).	>1.0s, 2.0s

² Not all ports shown are necessarily supported by the hardware. Consult the appropriate Instruction manual for details of the ports available on specific hardware.

Configuring the FieldServer

Example

```
// Server Side Nodes  
Nodes  
Node_Name      , Node_ID   , Protocol  
HCSR_01        , 240       , HCS-R
```

5.3 Server Side Map Descriptor Parameters

5.3.1 FieldServer Specific Map Descriptor Parameters

Column Title	Function	Legal Values
Map_Descriptor_Name	Name of this Map Descriptor.	Up to 32 alphanumeric characters
Data_Array_Name	Name of Data Array where data is to be stored in the FieldServer.	One of the Data Array names from "Data Array" section above
Data_Array_Offset	Starting location in Data Array.	0 to (Data_Array_Length-1) as specified in "Data_Array" section
Function	Function of Server Map Descriptor.	Passive
Server_Hold_Timeout*	Specifies the time that the FieldServer will reserve the Server side connection while waiting for the Client side to update data in Data_Array (if necessary).	>1.0s, 2.0s

5.3.2 Driver Specific Map Descriptor Parameters

Column Title	Function	Legal Values
Node_Name	Name of Node to which data has to be sent.	One of the Node names specified in the Server "Node" section above
Length	Length of Map Descriptor.	22
Data_Type*	Specify format of the data to Serve. Refer to Section 6.2	Digi_Input, Ana_Input

5.4 Map Descriptor Example – SMD_HCSR_01 Map Descriptor to Serve HCS-R Clients

```
// Server Side Map Descriptors  
Map_Descriptors  
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Length , Scada_Hold_Timeout  
SMD_HCSR_01        , DA_HCSR       , 0           , Passive  , HCSR_01  , 22       , 5
```

Example comments:

- Data_Array_Name – Parameter defined in the data array section.
- Data_Array_Offset – The starting location of data to serve within the Data Array.
- Length – The number of items within the Data Array which will be used to prepare the response to the HCS-R Client.

6 Reference

6.1 How Client Stores Data

The HCS will be polled by an RDBC Map Descriptor and data will be stored in the DA_Current Data Array in the following fashion if parameter HCSR_Data_Stages >1:

- New data is stored as current data.
- If data is changed, last current data is moved to 2nd Stage, 2nd Stage data is moved to 3rd stage and 3rd stage data is lost.
- When a vehicle has HCS-R equipment installed, Byte 7 (Status of the loop) is equivalent to the “From Loop (0), On Loop (1) byte listed in [Section 6.1.1](#). The 20th offset will hold whether data is From Loop or On Loop. To achieve this, the FieldServer should be configured to store On-Loop and From-Loop data in the same Data Array. i.e. Map Descriptor Parameter HSCR_Onfrom should be set to Onfrom. Refer to [Section 4.3.2](#).

6.1.1 Data_Type is Ana_Input or Not Specified

Data Array Offset	Description
Current Data	
0 - 18	Data bits (0 - 1)
19	Receipt ok (0), Disturbance (1)
20	From Loop (0), On Loop (1)
21	Loop Number (1,2,3,4) as integer
2nd (Previous) Data	
24 – 42	Data bits (0 – 1)
43	Receipt ok (0), Disturbance (1)
44	From Loop (0), On Loop (1)
45	Loop Number (1,2,3,4) as integer
3rd (Prior to previous) Data	
48 – 66	Data bits (0 – 1)
67	Receipt ok (0), Disturbance (1)
68	From Loop (0), On Loop (1)
69	Loop Number (1,2,3,4) as integer

6.1.2 Data_Type is Digi_Input

Data Array Offset	Description
Current Data	
0 - 18	Data bits (0 - 1)
19	Receipt ok (0), Disturbance (1)
20	From Loop (0), On Loop (1)
3 bits for Loop Number Offsets 21 22 23	
21,22,23	1 0 0 – Loop 1 0 1 0 – Loop 2 1 1 0 – Loop 3 0 0 1 – Loop 4
2nd (Previous) Data	
24 – 42	Data bits (0 – 1)
43	Receipt ok (0), Disturbance (1)
44	From Loop (0), On Loop (1)
45	Loop Number (1,2,3,4) in 3 bits as above
3rd (Prior to previous) Data	
48 – 66	Data bits (0 – 1)
67	Receipt ok (0), Disturbance (1)
68	From Loop (0), On Loop (1)
69	Loop Number (1,2,3,4) in 3 bits as above

The same data will be stored in a Loop based Data Array which will then have the last known data for each loop.

Data Array Offset	Description
Current Data	
0 - 18	Data bits (0 – 1)
19	Receipt ok (0), Disturbance (1)
20	From Loop (0), On Loop (1)
2nd (Previous) Data	
21 – 39	Data bits (0 – 1)
40	Receipt ok (0), Disturbance (1)
41	From Loop (0), On Loop (1)
3rd (Prior to previous) Data	
42 – 60	Data bits (0 – 1)
61	Receipt ok (0), Disturbance (1)
62	From Loop (0), On Loop (1)

6.2 How Server Expects Data

The Server expects data in the following format in order to constitute its response to HCS-R Clients.

6.2.1 Data_Type is Ana_Input or Not Specified

Data Array Offset	Description
0 - 18	Data bits (0 - 1)
19	Receipt ok (0), Disturbance (1)
20	From Loop (0), On Loop (1)
21	Loop Number (0,1,2,3)

6.2.2 Data_Type is Digi_Input

Data Array Offset	Description
0 - 18	Data bits (0 - 1)
19	Receipt ok (0), Disturbance (1)
20	From Loop (0), On Loop (1)
21, 22	2 bits for Loop Number Offsets 21 & 22 0 0 – Loop 1 1 0 – Loop 2 0 1 – Loop 3 1 1 – Loop 4