

## Driver Manual

# FS-8700-146 KNX

### **APPLICABILITY & EFFECTIVITY**

Effective for all systems manufactured after June 2023.



Driver Revision: 1.07  
Document Revision: 3.D



**fieldserver**

MSA Safety  
1000 Cranberry Woods Drive  
Cranberry Township, PA 16066 USA  
Website: [www.MSAsafety.com](http://www.MSAsafety.com)

U.S. Support Information:  
+1 408 964-4443  
+1 800 727-4377  
Email: [smc-support@msasafety.com](mailto:smc-support@msasafety.com)

EMEA Support Information:  
+31 33 808 0590  
Email: [smc-support.emea@msasafety.com](mailto:smc-support.emea@msasafety.com)

## Contents

<b>1</b>	<b>KNX Description</b> .....	<b>2</b>
<b>2</b>	<b>Driver Scope of Supply</b> .....	<b>2</b>
2.1	Provided by the Supplier of 3 <sup>rd</sup> Party Equipment .....	2
2.1.1	Required 3 <sup>rd</sup> Party Hardware .....	2
<b>3</b>	<b>Hardware Connections</b> .....	<b>3</b>
<b>4</b>	<b>Data Array Parameters</b> .....	<b>4</b>
<b>5</b>	<b>Configuring the FieldServer as a KNX Client</b> .....	<b>5</b>
5.1	Client Side Connection Parameters .....	5
5.2	Client Side Node Parameters .....	6
5.3	Client Side Map Descriptor Parameters .....	6
5.3.1	FieldServer Specific Map Descriptor Parameters .....	6
5.3.2	Driver Related Map Descriptor Parameters .....	6
5.4	Map Descriptor Examples .....	7
5.4.1	Example 1 .....	7
5.4.2	Example 2 .....	8
5.4.3	Example 3 .....	8
<b>6</b>	<b>Configuring the FieldServer as a KNX Server</b> .....	<b>9</b>
6.1	Server Side Connection Parameters .....	9
6.2	Server Side Node Parameters .....	10
6.3	Server Side Map Descriptor Parameters .....	10
6.3.1	FieldServer Specific Map Descriptor Parameters .....	10
6.3.2	Driver Related Map Descriptor Parameters .....	10
6.4	Map Descriptor Examples .....	11
6.4.1	Example 1 .....	11
6.4.2	Example 2 .....	11
<b>7</b>	<b>Reference</b> .....	<b>12</b>
7.1	KNX Data Types .....	12
7.2	Calculating the Free Level Address .....	12
<b>8</b>	<b>Troubleshooting</b> .....	<b>13</b>
8.1	Driver Messages .....	13
8.2	User Statistic Messages .....	13

## 1 KNX Description

The KNX driver allows the FieldServer to transfer data to and from devices using KNX protocol. The Fieldbus connection is included with the FieldServer. The FieldServer can emulate a Passive Client.

KNX driver enables data access from KNX networks to other FieldServer protocols. Most KNX data point types are supported, allowing communication to almost any kind of KNX device in the installation, such as temperature sensors, shutters, light switches, actuators, alarms etc. This allows BMS systems to access a KNX network using direct read and write of KNX configured groups. This setup does not require the use of ETS4 to configure the QuickServer KNX gateway.

The KNX protocol is a connectionless protocol and therefore supports multiple clients and multiple servers.

The QuickServer is intended to act as a Passive Client on the KNX bus and make information available to other protocols.

### Supported Data Point Types

Data Point Name	Description
DPT1	1-bit Binary Switch
DPT2	2-bit Step Control
DPT3	4-bit Dimming
DPT4	8-bit Set
DPT5	8-bit Unsigned Value
DPT6	8-bit Signed Value
DPT7	16-bit Unsigned Value
DPT8	16-bit Signed Value
DPT9	16-bit Floating point value
DPT12	32-bit Unsigned Value
DPT13	32-bit Signed Value
DPT14	32-bit Float
DPT15	32-bit Access
DPT17	8-bit Scene Number
DPT18	8-bit Scene Control
DPT20	8-bit Enum Value

### Maximum Nodes Supported

FieldServer Mode	Nodes	Comments
Client	255	Maximum number in a KNX bus zoned

## 2 Driver Scope of Supply

### 2.1 Provided by the Supplier of 3<sup>rd</sup> Party Equipment

#### 2.1.1 Required 3<sup>rd</sup> Party Hardware


Part #	Description
	KNX Bus power supply

## 3 Hardware Connections

The FieldServer is connected to the KNX bus as shown in connection drawing.

Configure the KNX bus according to manufacturer's instructions (i.e. ETS5).

**NOTE: A KNX compatible power supply is required on the KNX network. The KNX Bus voltage needs to be between 21 and 30 VDC.**



## 4 Data Array Parameters

Data Arrays are “protocol neutral” data buffers for storage of data to be passed between protocols. It is necessary to declare the data format of each of the Data Arrays to facilitate correct storage of the relevant data.

Section Title		
Data_Arrays		
Column Title	Function	Legal Values
Data_Array_Name	Provide name for Data Array.	Up to 15 alphanumeric characters
Data_Array_Format	Provide data format. Each Data Array can only take on one format.	Float, Bit, Byte, Uint16, Uint32, Sint16, Sint32
Data_Array_Length	Number of Data Objects. Must be larger than the data storage area required by the Map Descriptors for the data being placed in this array.	1-10000

Datapoint Name	Description	Recommended Data Array Value
DPT1	1-bit Binary Switch	BYTE
DPT2	2-bit Step Control	BYTE
DPT3	4-bit Dimming	BYTE
DPT4	8-bit Set	BYTE
DPT5	8-bit Unsigned Value	BYTE
DPT6	8-bit Signed Value	SINT16
DPT7	16-bit Unsigned Value	UINT16
DPT8	16-bit Signed Value	SINT16
DPT9	16-bit Floating point value	FLOAT
DPT12	32-bit Unsigned Value	UINT32
DPT13	32-bit Signed Value	SINT32
DPT14	32-bit Float	FLOAT
DPT15	32-bit Access	UINT32
DPT17	8-bit Scene Number	BYTE
DPT18	8-bit Scene Control	BYTE
DPT20	8-bit Enum Value	BYTE

### Example

```
// Data Arrays
Data_Arrays
Data_Array_Name , Data_Array_Format , Data_Array_Length
DA_KNX_01 , UINT16 , 50
DA_KNX_02 , UINT32 , 50
DA_KNX_03 , BYTE , 50
DA_KNX_04 , FLOAT , 50
```

## 5 Configuring the FieldServer as a KNX Client

For detailed information on FieldServer configuration, refer to the FieldServer Configuration Manual. The information that follows describes how to expand upon the factory defaults provided in the configuration files included with the FieldServer (see “.csv” sample files provided with the FieldServer). This section documents and describes the parameters necessary for configuring the FieldServer to communicate with a KNX device (Server).

The configuration file tells the FieldServer about its interfaces, and the routing of data required. In order to enable the FieldServer for KNX bus communications, the driver independent FieldServer buffers need to be declared in the “Data Arrays” section, the destination device addresses need to be declared in the “Client Side Nodes” section, and the data required from the servers needs to be mapped in the “Client Side Map Descriptors” section. Details on how to do this can be found below.

**NOTE:** In the tables below, \* indicates an optional parameter, with the bold legal value as default.

### 5.1 Client Side Connection Parameters

Section Title		
Connections		
Column Title	Function	Legal Values
Port	Specify which port the device is connected to the FieldServer.	R2
Protocol	Specify protocol used.	KNX
Physical_Address	Free level address, 4 character Hex value (max FFFF), e.g. ffff = 15,15,255.	0-FFFF
	2 part scheme, e.g. 1.15 = 0,1,15.	[0-255].[0-255]
	3 part scheme (e.g. 1.2.31).	[0-15].[0-15].[0-255]
Retries	Specify the number of retries (KNX bus handles this automatically).	0
Recovery_Interval	Specify the period between retries (recommend 60s).	0-32000s, <b>60s</b>

#### Example 1:

The QuickServer is configured as a KNX Client with the KNX physical address of 1.1.128 using the hexadecimal address scheme.

Connections								
Port	,	Protocol	,	Physical_Address	,	Retries	,	Recovery_Interval
R2	,	KNX	,	1180	,	0	,	60s

#### Example 2:

The QuickServer is configured as a KNX Client with the KNX physical address of 1.1.128 using the 2 part decimal address scheme.

Port	,	Protocol	,	Physical_Address	,	Retries	,	Recovery_Interval
R2	,	KNX	,	17.128	,	0	,	60s

#### Example 3:

The QuickServer is configured as a KNX Client with the KNX physical address of 1.1.128 using the 3 part decimal address scheme.

Port	,	Protocol	,	Physical_Address	,	Retries	,	Recovery_Interval
R2	,	KNX	,	1.1.128	,	0	,	60s

## 5.2 Client Side Node Parameters

Section Title		
Nodes		
Column Title	Function	Legal Values
Node_Name	Provide name for Node.	Up to 32 alphanumeric characters
Protocol	Specify Protocol used.	KNX
Port	Specify through which port the device is connected to the FieldServer.	R2

### Example

```
// Client Side Nodes

Nodes
Node_Name      , Protocol  , Port
KNX_Bridge_1  , KNX      , R2
```

## 5.3 Client Side Map Descriptor Parameters

### 5.3.1 FieldServer Specific Map Descriptor Parameters

Column Title	Function	Legal Values
Map_Descriptor_Name	Name of this Map Descriptor.	Up to 32 alphanumeric characters
Data_Array_Name	Name of Data Array where data is to be stored in the FieldServer.	One of the Data Array names from <b>Section 4</b>
Data_Array_Offset	Starting location in Data Array.	0 to (Data_Array_Length-1) as specified in <b>Section 4</b>
Function	Function of Client Map Descriptor.	Rdbc, Wrbc, Wrbx, ARS

### 5.3.2 Driver Related Map Descriptor Parameters

Column Title	Function	Legal Values
Node_Name	Name of Node to fetch data from.	One of the Node names specified in <b>Section 5.2</b>
Data_Type	Data type.	See <b>7</b>
Group_Address	Free level address, 4 character Hex value (max FFFF), e.g. ffff = 15,15,255.	0-FFFF; Calculation specified in <b>Section 7.2</b>
	2 part scheme, e.g. 1.15 = 0,1,15.	[0-255].[0-255]
	3 part scheme (e.g. 1.2.31).	[0-31]/[0-7]/[0-255]
Linked_Map_Descriptor	If a Group address should be linked to another Group address' data array.	One of the Map descriptor names specified in <b>Section 5.3</b> , otherwise leave blank with "-"
Read_Response	QuickServer is not intended to respond to Read requests ("No" recommended), but this could be set ("Yes") to do so.	No, Yes



## 5.4 Map Descriptor Examples

### 5.4.1 Example 1

The QuickServer is configured to store writes or other read responses. It will also generate a write should the data array update. KNX\_VAR1\_LINK data array is updated with a group 0.5.2 value update as it is linked to KNX\_VAR1 data array.

```
// Client Side Map Descriptors

// Linked map descriptor example, any store to a linked map descriptor will update the parent.
Map_Descriptors
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Data_Type
KNX_VAR1 , DA_KNX1 , 00 , ARS , KNX_Read_1 , DPT1
KNX_VAR1_LINK , DA_KNX1 , 01 , PASSIVE , KNX_Read_1 , DPT1

, Group_Address , Linked_Map_Descriptor
, 0/5/01 , -
, 0/5/02 , KNX_VAR1
```

#### Example comments:

- Map\_Descriptor\_Name – Map descriptor KNX\_VAR1 maps the value for the KNX group address 0:5:1. Map descriptor KNX\_VAR1\_LINK maps the value for the KNX group address 0:5:2.
- Data\_Array\_Name & Data\_Array\_Offset – Both map descriptors use the same data array (DA\_KNX1) but reference the data at different offsets.
- Function – ARS is the most common function for KNX clients, as it will send out a KNX read to the group on start-up, and from then on it will be passive.
- Data\_Type – The data point type must be compatible with the KNX group address it is associated with. The following data types are also available: DPT1, DPT2, DPT3, DPT4, DPT5, DPT6, DPT7, DPT8, DPT9, DPT12, DPT13, DPT14, DPT15, DPT17, DPT18, DPT20.
- Goup\_Address – The associated group address for the map descriptor is specified in this field.
- Linked\_Map\_Descriptor – The linked map descriptor pair must be of the same data.

## 5.4.2 Example 2

The QuickServer is configured to have a readable KNX point. By default, the QuickServer is not intended to respond to group read message, so this map descriptor is specifically set to yes. This will be used to provide data to the KNX network if a read response is requested.

```
// Client Side Map Descriptors
Map_Descriptors
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Data_Type
KNX_VAR1 , DA_KNX1 , 00 , PASSIVE , KNX_Read_2 , DPT1
, Group_Address , Read_Response
, 0/5/05 , Yes
```

### Example comments:

- Read\_Response – The map descriptor is set to respond to the group request.

## 5.4.3 Example 3

The QuickServer is configured to write to a group address when the data array is updated.

```
// Client Side Map Descriptors
Map_Descriptors
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Data_Type , Group_Address
KNX_LIGHT1 , DA_KNX2 , 00 , WRBX , KNX_Write_1 , DPT1 , 0/5/03
KNX_LIGHT2 , DA_KNX2 , 01 , WRBX , KNX_Write_2 , DPT1 , 0/5/04
```

### Example comments:

- Function – The map descriptor is set to write a change of value to the group specified.

## 6 Configuring the FieldServer as a KNX Server

For detailed information on FieldServer configuration, refer to the FieldServer Configuration Manual. The information that follows describes how to expand upon the factory defaults provided in the configuration files included with the FieldServer (see “.csv” sample files provided with the FieldServer). This section documents and describes the parameters necessary for configuring the FieldServer to be a KNX Server.

**NOTE:** In the tables below, \* indicates an optional parameter, with the bold legal value as default.

### 6.1 Server Side Connection Parameters

Section Title		
Connections		
Column Title	Function	Legal Values
Port	Specify which port the device is connected to the FieldServer.	R2
Protocol	Specify protocol used.	KNX
Physical_Address	4 character Hex value (max FFFF), e.g. ffff = 15,15,255.	0-FFFF
	2 part scheme, e.g. 1.15 = 0,1,15.	[0-255].[0-255]
	3 part scheme (e.g. 1.2.31).	[0-15].[0-15].[0-255]
Retries	Specify the number of retries (KNX bus handles this automatically).	0
Recovery_Interval	Specify the period between retries (recommend 60s).	0-32000s, <b>60s</b>

#### Example 1:

The QuickServer is configured as a KNX Server with the KNX physical address of 1.1.16 using the hexadecimal address scheme.

Connections					
Port	Protocol	Physical_Address	Retries	Recovery_Interval	
R2	, KNX	, 1110	, 0	, 60s	

#### Example 2:

The QuickServer is configured as a KNX Client with the KNX physical address of 1.1.16 using the 2 part decimal address scheme.

Port	Protocol	Physical_Address	Retries	Recovery_Interval	
R2	, KNX	, 17.10	, 0	, 60s	

#### Example 3:

The QuickServer is configured as a KNX Client with the KNX physical address of 1.1.16 using the 3 part decimal address scheme.

Port	Protocol	Physical_Address	Retries	Recovery_Interval	
R2	, KNX	, 1.1.16	, 0	, 60s	

## 6.2 Server Side Node Parameters

Section Title		
Nodes		
Column Title	Function	Legal Values
Node_Name	Provide name for Node.	Up to 32 alphanumeric characters
Protocol	Specify Protocol used.	KNX
Port	Specify through which port the device is connected to the FieldServer.	R2

### Example

```
// Client Side Nodes

Nodes
Node_Name      , Protocol  , Port
KNX_Bridge_1  , KNX      , R2
```

## 6.3 Server Side Map Descriptor Parameters

### 6.3.1 FieldServer Specific Map Descriptor Parameters

Column Title	Function	Legal Values
Map_Descriptor_Name	Name of this Map Descriptor.	Up to 32 alphanumeric characters
Data_Array_Name	Name of Data Array where data is to be stored in the FieldServer.	One of the Data Array names from <b>Section 4</b>
Data_Array_Offset	Starting location in Data Array.	0 to (Data_Array_Length-1) as specified in <b>Section 4</b>
Function	Function of Server Map Descriptor.	SERVER

### 6.3.2 Driver Related Map Descriptor Parameters

Column Title	Function	Legal Values
Node_Name	Name of Node to fetch data from.	One of the Node names specified in <b>Section 6.2</b>
Data_Type	Data type	See <b>Section 7</b>
Group_Address	KNX Group Address Value associated with the data array (Hexidecmal value max FFFF).	[0-31]/[0-7]/[0-255]
Linked_Map_Descriptor	If a Group address should be linked to another Group address' data array.	One of the Map descriptor names specified in <b>Section 6.3</b> , otherwise leave blank with "-"
Read_Response	QuickServer is not intended to respond to Read requests ("No" recommended), but this could be set ("Yes") to do so.	No, Yes

## 6.4 Map Descriptor Examples

### 6.4.1 Example 1

The QuickServer is configured to store writes or other read responses. It will also generate a write should the data array update. KNX\_VAR1\_LINK data array is updated with a group 0.5.2 value update as it is linked to KNX\_VAR1 data array.

```
// Server Side Map Descriptors

// Linked map descriptor example, any store to a linked map descriptor will update the parent.
Map_Descriptors
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Data_Type
KNX_VAR1 , DA_KNX1 , 00 , SERVER , KNX_Status_1 , DPT1
KNX_VAR1_LINK , DA_KNX1 , 01 , SERVER , KNX_Status_1 , DPT1

, Group_Address , Read_Response
, 0/5/01 , Yes
, 0/5/02 , No
```

#### Example comments:

- Map\_Descriptor\_Name – Map descriptor KNX\_VAR1 maps the value for the KNX group address 0:5:1. Map descriptor KNX\_VAR1\_LINK maps the value for the KNX group address 0:5:2.
- Data\_Array\_Name & Data\_Array\_Offset – Both map descriptors use the same data array (DA\_KNX1) but reference the data at different offsets.
- Function – SERVER function is used for KNX servers, as it will store any KNX telegram associated with the configured group as a passive device on the bus.
- Data\_Type – The data point type must be compatible with the KNX group address it is associated with. The following data types are also available: DPT1, DPT2, DPT3, DPT4, DPT5, DPT6, DPT7, DPT8, DPT9, DPT12, DPT13, DPT14, DPT15, DPT17, DPT18, DPT20.
- Goup\_Address – The associated group address for the map descriptor is specified in this field.
- Read\_Response – If the QuickServer server point has to serve the data to another client device requesting the data, set this to “Yes”. If the QuickServer only has to capture the group status set by another server on the given group address, set this parameter to “No”.

### 6.4.2 Example 2

These examples show how to configure writes on the Server Side.

```
// Server Side Map Descriptors

Map_Descriptors
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Data_Type
KNX_RD_VAR_1 , DA_Rd_01 , 0 , SERVER , Dev_KNX , DPT9
KNX_WR_VAR_1 , DA_Wr_01 , 0 , SERVER , Dev_KNX , DPT9

, Group_Address , Read_Response , Linked_Map_Descriptor
, 1:1:1 , YES , -
, 1:2:1 , NO , KNX_RD_VAR_1
```

## 7 Reference

### 7.1 KNX Data Types

KNX Data point Name	Description	Recommended Data Array Value
DPT1	1-bit Binary Switch	BYTE
DPT2	2-bit Step Control	BYTE
DPT3	4-bit Dimming	BYTE
DPT4	8-bit Set	BYTE
DPT5	8-bit Unsigned Value	BYTE
DPT6	8-bit Signed Value	SINT16
DPT7	16-bit Unsigned Value	UINT16
DPT8	16-bit Signed Value	SINT16
DPT9	16-bit Floating point value	FLOAT
DPT12	32-bit Unsigned Value	UINT32
DPT13	32-bit Signed Value	SINT32
DPT14	32-bit Float	FLOAT
DPT15	32-bit Access	UINT32
DPT17	8-bit Scene Number	BYTE
DPT18	8-bit Scene Control	BYTE
DPT20	8-bit Enum Value	BYTE

### 7.2 Calculating the Free Level Address

For Group addresses exceeding 255, you will need to convert the Group Address to the Free Level Address. This is done by converting the components of the Group Address to binary values, adding them together, and then converting the final value to Hex.

For example, Group address 13/2047 will be converted as follows:

13 converted to binary is 1101.

2047 converted to binary is 0111 1111 1111.

13 (binary) added to 2047 (binary) is 1101 0111 1111 1111 which, converted to Hex, equals D7FF.

The Map Descriptor will then list the Group\_Address as follows:

```
Map_Descriptors
Map_Descriptor_Name , Data_Array_Name , Data_Array_Offset , Function , Node_Name , Data_Type , Group_Address
KNX_DPT1 , DA_AI_01 , 0 , ars , KNX_Bridge_1 , DPT1 , D7FF
```

## 8 Troubleshooting

### 8.1 Driver Messages

Msg #	Msg Screen	Screen Message	Meaning	Suggested Solution
1	DRIVER	KNX : KNX DEV CMD=x, SEQ=x, ACK   NAK	When the QuickServer is discovered in ETS, the various commands are listed with an ACK/NAK depending on the outcome of the request.	This is general information with no action to take.

### 8.2 User Statistic Messages

Msg #	View	Statistic	Meaning	Suggested Solution
1	Connection	TPUART echo fail	The communication between the QuickServer and the KNX hardware was interrupted. This problem is associated with a bad KNX connection, or an undervoltage condition on the KNX bus.	Check connection and/or KNX bus voltage.