

Description

The LonWorks driver allows the FieldServer to transfer data to and from devices using LonWorks protocol. Data transfer occurs via TP/FT10 twisted pair interface with an exhaustive list of protocols including Modbus, BACnet etc. Data transfer is via 2 basic functional blocks, Input and Output allowing Float and Word SNVT data types.

The FieldServer LonWorks driver can facilitate up to 4096 Network Variables, the ProtoNode, ProtoCessor and QuickServer up to 3000 Network Variables which can be of the Standard Network Variable Types (SNVT) and/or User-defined Network Variable Types (UNVT).

The FieldServer LonWorks device can be used with explicit and/or implicit addressing and can be bound to a maximum of 15 other LonWorks nodes. The FieldServer can handle a maximum of 3000 explicitly addressed nodes. The FieldServer currently supports a default of 63 network variable aliases to avoid network variable connection constraints.

The FieldServer can transfer data (Network Variables) in two ways:

- It can poll (request data from) other devices at a regular interval.
- It can send Network Variable Updates:
 - At a regular interval
 - When the data has changed
 - In throttled mode using minimum and maximum send time and change on delta parameters

The FieldServer is capable of being configured by Network Management Tools such as LonMaker. For binding (implicit mode), a Network Management Tool is necessary to create the bindings. It is possible to place a FieldServer into a Network for explicit communications without using a Network Management Tool, but this requires intimate knowledge of the network in question.

The external interface file (XIF) for the FieldServer can be uploaded from the FieldServer for the application. The FieldServer differs from most other LonWorks devices in that its XIF file is not fixed due to varying applications. The list of points available to the network will vary depending on the other networks connected to the FieldServer, and the requirements of the application. The recommended procedure for obtaining the XIF file for the FieldServer is to upload it.

The following FieldServer Platforms are LonMark Certified:

- ProtoCessor
- ProtoNode
- QuickServer



The FieldServer provides the capability of defining multiple functional blocks, but only a single LonMark object. The user can create multiple functional blocks or a LonMark object by filling out the Node self documentation string and the respective Network variable self-documentation string fields in the FieldServer configuration file.

The following table summarizes the FieldServer LonWorks driver’s capabilities:

ProtoCessor, ProtoNode & QuickServer Capabilities	
Address Table Entries	15
Network Variable Aliases	63
Number of Domain Tables [1]	2
Support for SNVTs [2]	Yes
Support for UNVTs	Yes
Explicit Addressing	Yes
Implicit Addressing	Yes
XIF File	Yes
Acknowledged service	Yes
Unacknowledged service	Yes
Supports Polled Network Variables	Yes
Supports Network Variable Updates	Yes
Supports Configuration Properties [3]	Yes
Supports Node and Network Variable Self-Documentation Strings	Yes
Support for SCPTs [4]	Yes
Network Management Tools such as LonMaker Supported	Yes
Commissioning without Network Management Tool Supported [5]	Yes
Service Pin Supported	Yes
LonMark Object and Functional Profiles definition [6]	Yes

[1] One of the two domains is the zero domain used by Network Management Tools.

[2] SNVT master list version 12 is supported with some exceptions.

[3] Implemented with configuration Network variables.

[4] Only selected SCPTs are supported, extra SCPTs can be added on a per configuration basis.

[5] Explicit addressing only.

[6] Only approved LonMark objects are supported, see www.lonmark.org.

Connection Facts

FieldServer Mode	Nodes	Comments
Client	1	The FieldServer can only represent one LonWorks device on the LonWorks Network. A LonWorks device is unique in terms of its Neuron Chip Identification Number.
Server	1	

Formal Driver Type

Fieldbus, Client or Server

Compatibility

FieldServer Model	Compatible
ProtoCessor	Yes
ProtoCarrier	Yes
ProtoNode	Yes
ProtoAir	No

FieldServer Model	Compatible
QuickServer FS-QS-10xx	Yes
QuickServer FS-QS-12xx	Yes
QuickServer FS-QS-20xx	No
QuickServer FS-QS-22xx	No
QuickServer FS-QS-3x10-F	No

MSA Safety

1000 Cranberry Woods Drive, Cranberry Township, PA 16066 USA

O. +1 408 964-4443 **TF.** +1 800 727-4377 **E.** SMC-insidesales@msasafety.com

www.MSAsafety.com

Connection Information

Connection Type: FTT-10 Free Topology Network Transceiver

Baud Rates: 78125 bps (bits per second)

Hardware Interface: Built in LonWorks FTT-10 interface (ProtoCessor, ProtoNode and QuickServer)

Additional information on cabling and junction boxes that may be used in twisted pair LonWorks networks are detailed in the following Echelon publication: http://downloads.echelon.com/support/documentation/bulletin/005-0023-01O_Jbox_wiring.pdf

Devices Tested

Device	Tested (Factory, Site)
LonMaker for Windows V3.1	Factory/Site
TAC Xenta	Factory/Site
TAC VISTA	Site
Electronic Systems USA	Factory
Echelon I/Lon 100	Site
Plexus Technologies	Site
Invensys I/A Series	Factory
Circon UHC 300 (and others)	Factory
Distech	Site
PureChoice Nose	Factory/Site
Honeywell	Factory/Site
...and many others	

Communication Functions

Data Types Supported	
FieldServer Data Type	Description (or Device Data Type)
Integers (long, short, signed, unsigned)	SNVTs* and UNVTs can be presented, stored and moved into any FieldServer data type. NOTE: For supported SNVTs, see the LonWorks manual.
Float	
Byte	
Bit	

Read Operations Supported	
FieldServer as a Client	FieldServer as a Server
Polled Network variables:	Polled Network variables:
Send Network variable fetch	Respond to Network variable fetch
Send Network variable poll	Respond to Network variable poll

Write (Control) Operations Supported	
FieldServer as a Client	FieldServer as a Server
Send Network variable updates	Accept Network variable updates

Unsupported Functions and Data Types	
Function	Reason
Programming Messages	FieldServer is a data transfer device therefore programming messages are not required.
Direct Memory Read / Writes Under User Control	The driver uses the Echelon MIP which handles direct memory read and writes.
LonMark File Transfer Protocol	The driver does not support reading and writing remote configuration properties implemented as files. The driver doesn't support the LonMark File transfer protocol commonly used to access these remote files.

LonWorks Configuration Properties (SCPTs or UCPTs)

The Driver can read and write remote configuration properties implemented as Network variables.

MSA Safety

1000 Cranberry Woods Drive, Cranberry Township, PA 16066 USA

O. +1 408 964-4443 TF. +1 800 727-4377 E. SMC-insidesales@msasafety.com

www.MSAsafety.com