

FieldServer Protocol Driver Sheet

GE-SNP Protocol Serial Driver

FS-8700-66 Version: 1.05 / Rev. 1

1 DESCRIPTION

The GE-SNP Serial driver allows the FieldServer to transfer data to and from devices over either RS-232 or RS-485 using GE-SNP Serial protocol. The FieldServer can emulate either a Server or Client.

The FieldServer provides functions to read and write PLC memory and change the privilege level. Standard SNP mailbox messages are used. The driver does not support Datagram messages and cannot parse them. These messages are defined by the SNP protocol to allow multiple data types to be packed into one message. They are not commonly used by the HMI and 3rd party applications and are inconsistent with the FieldServer's *Write Through and Port Expander* capabilities.

The driver can expose communications statistics in a Data Array so that downstream devices can monitor them.

1.1 Connection Facts

FieldServer Mode	Nodes	Comments
Client	1	Only 1 Client node allowed on Multidrop systems
Server		

2 FORMAL DRIVER TYPE

Serial

Client or Server

3 **COMPATIBILITY MATRIX**

FieldServer Model	Compatible with this driver
FS-x30	Yes
SlotServer	Yes
ProtoNode	Yes
QuickServer FS-QS-10xx	No
QuickServer FS-QS-12xx	Yes
ProtoCessor FPC-ED2	Yes
ProtoCessor FPC-ED4	Yes

4 CONNECTION INFORMATION

Connection type: RS-232 or RS-485 (Two wire,

Half-Duplex)

Baud Rates: 100-19200, standard baud

rates only (Vender imitation),

19200

Data Bits: 7,**8**Stop Bits: **1**,2

Parity: Odd, Even, **None**

Multidrop Capability: Yes

5 **DEVICES TESTED**

Device	Tested (FACTORY, SITE)	
Series 90-30 CPU 364	Factory & Site	
Intellution FIX32's SNP device driver.	Site	

6 COMMUNICATIONS FUNCTIONS – SUPPORTED FUNCTIONS AT A GLANCE

6.1 Data Types Supported

FieldServer Data Type	Description Data Type)	(or	Device
Analog Input			
Digital Input			
Analog Register			
Digital Register			
Analog Output			
Digital Output			



FieldServer Protocol Driver Sheet

GE-SNP Protocol Serial Driver

FS-8700-66 Version: 1.05 / Rev. 1

6.2 Read Operations Supported

FieldServer as a Client	FieldServer as a Server		
Discrete Inputs (%I)	Discrete Inputs (%I)		
Discrete Outputs (%Q)	Discrete Outputs (%Q)		
Discrete Temporaries	Discrete Temporaries		
(%T)	(%T)		
Discrete Internals (%M)	Discrete Internals (%M)		
Genius Global Data	Genius Global Data		
(%G)	(%G)		
Analog Inputs (%AI)	Analog Inputs (%AI)		
Analog Outputs (%AQ)	Analog Outputs (%AQ)		
Registers (%R)	Registers (%R)		
%SA Discrete	%SA Discrete		
%SB Discrete	%SB Discrete		
%SC Discrete	%SC Discrete		
%S Discrete (%S)	%S Discrete (%S)		

6.3 Unsupported Functions and Data Types

Function	Reason	
Programming messages	FieldServer is a data transfer device, and as such, programming messages are not required	
Datagram messages	These messages are defined by the SNP protocol to allow multiple data types to be packed into one message. They are not commonly used by the HMI and 3 rd party applications and are inconsistent with the FieldServer's Write Through and Port Expander capabilities.	